



Smart Sensors

Laser Displacement Sensors CMOS Type

ZX2 Series



User's Manual



CONTENTS

Introduction

Meanings of Signal Words	8
Meanings of Alert Symbols	8
Laser Safety	9
Precautions for Safe Use	11
Precautions for Correct Use	12
Precautions for Correct Use	12
How to Use This Manual	14

PREPARATION FOR MEASUREMENT

Part Names and Functions	18
Basic Configuration	18
Amplifier Unit	19
Sensor Head	22
Calculating Unit	22
Installation	23
Installing Sensor Heads	23
Installing the Amplifier Unit	24
Connecting Calculating Units	25
Connecting the Sensor Head to the Amplifier Unit	27
Wiring Diagram	28
Wiring Input/Output Cables	28
I/O Circuit Diagrams	31

FLOW OF OPERATION

FLOW OF OPERATION	34
-----------------------------	----

BASIC SETUP

BASIC SETUP	38
Display of RUN Mode	38
Simplest Setting	38

MAIN APPLICATIONS & SETTING METHODS

Height	40
Steps and Warpage	45

Double Sheet Detection	50
Thickness	55
Positioning	64
Eccentricity and Surface Deflection	70

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

DETAILED SETTINGS

Smart Tuning.	78
Connecting Two or More Amplifier Units	82
Mutual Interference Prevention	84
Setting the Hysteresis	87
Setting the Hold Function	89
Bank Setting	95
Zero Reset	97
Scaling	101
Analog Output	105
Output for Non-measurement	107
Timer	110
External Input for Bank, Timing Input, Reset Input	112
Key Lock Function	114
Initializing Settings Data	115

TROUBLESHOOTING

Troubleshooting	120
Error Messages	122
Q&A	125

SPECIFICATIONS

Specifications and Dimensions.	128
Amplifier Units	128
Sensor Heads	130
Sensor Head Extension Cables.	130
Calculating Unit	132
Timing Charts	133
Engineering Data (Typical)	136
Angle Characteristic	136
Linearity Characteristic for Different Materials.	137
Beam Size	138

INDEX 139

Revision History	143
----------------------------	-----

SETTING TRANSITION CHARTS 144

Introduction

Thank you for purchasing the ZX2 Series Smart Sensor. This manual provides information regarding functions, performance and operating methods that are required for using the sensor.

When using the ZX2 Smart Sensor, make sure to observe the following:

- The ZX2 Smart Sensor must be operated by personnel knowledgeable in electrical engineering.
- To ensure correct use, please read this manual thoroughly to deepen your understanding of the product.
- Please keep this manual in a safe place so that it can be referred to whenever necessary.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

READ AND UNDERSTAND THIS DOCUMENT

Please read and understand this document before using the products. Please consult your OMRON representative if you have any questions or comments.

WARRANTY

OMRON's exclusive warranty is that the products are free from defects in materials and workmanship for a period of one year (or other period if specified) from date of sale by OMRON.

OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, REGARDING NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR PARTICULAR PURPOSE OF THE PRODUCTS. ANY BUYER OR USER ACKNOWLEDGES THAT THE BUYER OR USER ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE. OMRON DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED.

LIMITATIONS OF LIABILITY

OMRON SHALL NOT BE RESPONSIBLE FOR SPECIAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, OR STRICT LIABILITY.

In no event shall responsibility of OMRON for any act exceed the individual price of the product on which liability is asserted.

IN NO EVENT SHALL OMRON BE RESPONSIBLE FOR WARRANTY, REPAIR, OR OTHER CLAIMS REGARDING THE PRODUCTS UNLESS OMRON'S ANALYSIS CONFIRMS THAT THE PRODUCTS WERE PROPERLY HANDLED, STORED, INSTALLED, AND MAINTAINED AND NOT SUBJECT TO CONTAMINATION, ABUSE, MISUSE, OR INAPPROPRIATE MODIFICATION OR REPAIR.

SUITABILITY FOR USE

THE PRODUCTS CONTAINED IN THIS DOCUMENT ARE NOT SAFETY RATED. THEY ARE NOT DESIGNED OR RATED FOR ENSURING SAFETY OF PERSONS, AND SHOULD NOT BE RELIED UPON AS A SAFETY COMPONENT OR PROTECTIVE DEVICE FOR SUCH PURPOSES. Please refer to separate catalogs for OMRON's safety rated products.

OMRON shall not be responsible for conformity with any standards, codes, or regulations that apply to the combination of products in the customer's application or use of the product.

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

At the customer's request, OMRON will provide applicable third party certification documents identifying ratings and limitations of use that apply to the products. This information by itself is not sufficient for a complete determination of the suitability of the products in combination with the end product, machine, system, or other application or use.

The following are some examples of applications for which particular attention must be given. This is not intended to be an exhaustive list of all possible uses of the products, nor is it intended to imply that the uses listed may be suitable for the products:

Outdoor use, uses involving potential chemical contamination or electrical interference, or conditions or uses not described in this document.

Nuclear energy control systems, combustion systems, railroad systems, aviation systems, medical equipment, amusement machines, vehicles, safety equipment, and installations subject to separate industry or government regulations.

Systems, machines, and equipment that could present a risk to life or property.

Please know and observe all prohibitions of use applicable to the products.

NEVER USE THE PRODUCTS FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

PERFORMANCE DATA

Performance data given in this document is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of OMRON's test conditions, and the users must correlate it to actual application requirements. Actual performance is subject to the OMRON Warranty and Limitations of Liability.

CHANGE IN SPECIFICATIONS

Product specifications and accessories may be changed at any time based on improvements and other reasons.

It is our practice to change model numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the product may be changed without any notice. When in doubt, special model numbers may be assigned to fix or establish key specifications for your application on your request. Please consult with your OMRON representative at any time to confirm actual specifications of purchased products.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

DIMENSIONS AND WEIGHTS

Dimensions and weights are nominal and are not to be used for manufacturing purposes, even when tolerances are shown.

ERRORS AND OMISSIONS

The information in this document has been carefully checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical, or proofreading errors, or omissions.

PROGRAMMABLE PRODUCTS

OMRON shall not be responsible for the user's programming of a programmable product, or any consequence thereof.

COPYRIGHT AND COPY PERMISSION

This document shall not be copied for sales or promotions without permission.

This document is protected by copyright and is intended solely for use in conjunction with the product. Please notify us before copying or reproducing this document in any manner, for any other purpose. If copying or transmitting this document to another, please copy or transmit it in its entirety.

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

Meanings of Signal Words

The following signal words are used in this manual.



Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or may result in serious injury or death. Additionally there may be significant property damage.

Meanings of Alert Symbols

The following alert symbols are used in this manual.



Indicates the possibility of laser radiation.



Indicates prohibition when there is a risk of minor injury from electrical shock or other source if the product is disassembled.

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

Laser Safety

■ ZX2-LD□□□ Sensor Head

WARNING

Never look into the laser beam.
Doing so continuously will result in visual impairment.



Do not disassemble the product.
Doing so may cause the laser beam to leak, resulting in the danger of visual impairment.



CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

The ZX2-LD□□□ Sensor Head is a Class 2 Laser Product according to EN 60825-1 (IEC 60825-1) and Class II Laser Product according to FDA (21 CFR1040.10) (see note). The ZX2 Series is meant to be built into final system equipment. Pay special attention to the following precautions for the safe use of the product:

Note: Europe: Class 1 and Class 2 of EN 60825-1: 1994 +A11:1996 +A2:2001
= IEC 60825-1:1993 +A1:1997 +A2:2001
U.S.A.: Class I and Class II of FDA (21 CFR1040.10)

- (1) ZX2-LD□□□ emits visual laser beam. Do not stare directly into the laser.
Make sure that the laser beam path is terminated. If specular objects are present in the laser beam path, make sure that they are prevented from reflecting the laser beam.
When used without an enclosure, make sure the laser path from eye level is avoided.
- (2) To avoid exposure to hazardous laser radiation, do not displace nor remove the protective housing during operation, maintenance, and any other servicing.
- (3) As for countries other than those of Europe and the U.S.A., observe the regulations and standards specified by each country.
- (4) Label Indications
The EN and FDA labels are supplied with the product.
Replace the current labels with them according to the instructions given in the manuals.

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS

Precautions for Safe Use

Please observe the following precautions for safe use of the products.

■ Installation Environment

- Do not use the product in environments where it can be exposed to inflammable/explosive gas.
- Do not install the product close to high-voltage devices and power devices in order to secure the safety of operation and maintenance.

■ Power Supply and Wiring

- The supply voltage must be within the rated range (DC12 to 24 V \pm 10%).
- Reverse connection of power supply is not allowed. Connection to AC power supply is also not allowed.
- Open-collector outputs should not be short-circuited.
- High-voltage lines and power lines must be wired separately from this product. Wiring them together or placing in the same duct may cause induction, resulting in malfunction or damage.
- Always turn off the power supply before connecting or disconnecting cables and connectors.

■ Others

- Do not attempt to dismantle, repair, or modify the product.
- Dispose of this product as industrial waste.

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

Precautions for Correct Use

Please observe the following precautions to prevent failure to operate, malfunctions, or undesirable effects on product performance.

Installation of the Product

■ Installation Site

Do not install the product in locations subjected to the following conditions:

- Ambient temperature outside the rating
- Rapid temperature fluctuations (causing condensation)
- Relative humidity outside the range of 35 to 85%
- Presence of corrosive or flammable gases
- Presence of dust, salt, or iron particles
- Direct vibration or shock
- Reflective sensor of intense light (such as other laser beams or electric arc-welding machines)
- Direct sunlight or near heaters
- Water, oil, or chemical fumes or spray
- Strong magnetic or electric field

Component Installation and Handling

■ Power Supply and Wiring

- To extend the output cables of amplifier units, shielded cables of the same specifications as the output cables must be used.
- When using a commercially available switching regulator, make sure that the FG terminal is grounded.
- If surge currents are present in the power lines, connect surge absorbers that suit the operating environment.
- When connecting two or more amplifier units by using calculating units, make sure that the linear GND lines of the amplifier units are connected to each other. Supply power to all connected amplifier units at the same time.
- Before turning ON the power after the product is connected, make sure that the power supply voltage is correct, there are no incorrect connections (e.g. load short-circuit) and the load current is appropriate. Incorrect wiring may result in breakdown of the product.
- The cables must be 10 m or shorter in total length, for both sensor head and amplifier units. To extend the cable from the sensor head, an optional extension cable (ZX2-XC□R) must be used. For extension of the cable of amplifier units, shielded cables of the same type must be used.
- When using calculating units, make sure that the linear GND lines of the amplifier units are connected to each other.

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

■ Warming Up

After turning ON the power supply, allow the product to stand for at least 10 minutes before use. The circuits are still unstable just after the power supply is turned ON, so measured values may fluctuate gradually.

■ Sensing Object

The product cannot accurately measure the following types of objects: Transparent objects, objects with an extremely low reflective sensor ratio, objects smaller than the beam size, objects with a large curvature, excessively inclined objects, etc.

■ Mutual Interference

Inserting a calculating unit between amplifier units can prevent mutual interference between two sensor heads. However, this may not work efficiently if one sensor head is saturated and a laser beam of the other sensor head is input. If you are interested in installing a calculating unit in order to prevent mutual interference, carry out a test using the actual system beforehand.

■ Maintenance

- Always turn OFF the power supply before adjusting or connecting/disconnecting the sensor head.
- Do not use thinner, benzene, acetone or kerosene to clean the sensor head and amplifier units. If large dust particles adhere to the front filter of the sensor head, use a blower brush (used to clean camera lenses) to blow them off. Do not blow the dust away with your mouth. To remove smaller dust particles, use a soft cloth (for lenses) with a small amount of alcohol. Take care not to wipe them off with excessive force.

Scratches on the filter may cause errors.

How to Use This Manual

Page Format

This section explains the page format by using the Setting for MAIN APPLICATIONS AND SETTING METHODS chapter as an example.

Index label

Shows the chapter and header titles with white characters.

Height

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

THICKNESS

Positioning

ECCENTRICITY AND SURFACE DEFLECTION

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

40 Height

ZX2 User's Manual

Header

Indicates the measurement contents.

Flow

Shows the flow of operation.

Operation procedure

Explains the operation procedure.

Explanation of Selection Menu

Provides a supplemental explanation of the selection menu.

Description of Operation

Explains how to perform the operation by using buttons.

Display

Shows what is displayed as a result of the operation.

Button Operation

Shows how to use the buttons.

Meanings of Symbols

Symbol	Meaning
Important	Indicates points that are important to achieve the full product performance, such as operational precautions and application procedures.
(For details about xxx, see page xx.)	Indicates pages where related information can be found.
Required (white characters on a black background)	Indicates a required setting in a setup procedure.
Optional (black characters on a white background)	Indicates an optional setting in a setup procedure.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS


PREPARATION FOR MEASUREMENT

Part Names and Functions	18
Installation	23
Wiring Diagram	28

Part Names and Functions

Basic Configuration


The basic configuration of the ZX2 series Smart Sensors is shown below.




See the following pages for details:

	Part Names and Functions	Specifications and Dimensions
Sensor Heads	p. 22	p. 130
Amplifier Units	p. 19	p. 128
Calculating Unit	p. 22	p. 132
Extension Cables	—	p. 130

Amplifier Unit



(*) Operating and Display Sections






- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS

Digital Displays

The information displayed on the main and sub-displays depends on the currently selected mode. The default mode is the RUN mode.

When the power is turned ON, the model of Amplifier Unit (ZX2-LDA) will be displayed on the main display and the channel number will be displayed on the sub-display. Subsequently, the Sensor Head software version will be displayed on the main display and the Amplifier Unit software version will be displayed on the sub-display.

These details are displayed for approximately five seconds, and then data for the RUN mode will be displayed.

Mode	Main display (upper section, red)	Sub-display (lower section, orange)
RUN	<p>The measured value (the value after the measurement conditions have been reflected) is displayed.</p> <p>For example, when the hold function is set, the held value will be displayed.</p> <p>Default measured values are as follows:</p>  <p>The diagram shows a side view of a sensor head. A horizontal line represents the measurement range, divided into 'NEAR side' and 'FAR side'. Below this, a smaller horizontal line represents the measurement center distance, with a central point labeled '0'. Arrows indicate the '+ indication' on the left and '- indication' on the right.</p>	<p>By pressing the  button, the HIGH threshold, LOW threshold, analog output value, resolution (max. value of measured value during one second - min. value), current value (value before execution of zero reset, hold, scaling and 2-sensor operation), and BANK are displayed in this order.</p>
MENU	<p>The function names are displayed in order by pressing the  buttons.</p>	<p>The setting for the function displayed on the main display is displayed.</p>

(For details on setting transition charts, see page 144.)









Alphabet Display Format

The alphabet appears on the main and sub-displays as shown in the following table.

A	B	C	D	E	F	G	H	I	J	K	L	M
<i>A</i>	<i>B</i>	<i>C</i>	<i>D</i>	<i>E</i>	<i>F</i>	<i>G</i>	<i>H</i>	<i>I</i>	<i>J</i>	<i>K</i>	<i>L</i>	<i>M</i>
N	O	P	Q	R	S	T	U	V	W	X	Y	Z
<i>N</i>	<i>O</i>	<i>P</i>	<i>Q</i>	<i>R</i>	<i>S</i>	<i>T</i>	<i>U</i>	<i>V</i>	<i>W</i>	<i>X</i>	<i>Y</i>	<i>Z</i>

Button Operation

The functions of buttons change according to the currently selected mode.

Button type		Button function	
		RUN mode	MENU mode
Cursor buttons	 button  button	<ul style="list-style-type: none"> Normal press: Changes the sub-display content. Both  buttons held down for three seconds: Locks button operation. 	Function changes depending on the setting. <ul style="list-style-type: none"> Switches the function display. Selects the digit of numerical values. Stops setting.
	 button	<ul style="list-style-type: none"> Normal press: Executes timing input. 	The function changes depending on the setting. <ul style="list-style-type: none"> Changes the selection menu. Changes numerical values.
	 button	<ul style="list-style-type: none"> Held down for one second: Executes zero reset. Both  buttons held down for one second: Cancels a zero reset. 	
	MENU/SET button 	<ul style="list-style-type: none"> Held down for 3 seconds: Changes the mode to the MENU mode. 	<ul style="list-style-type: none"> Normal press: Finalizes the set condition or value. Held down for 3 seconds: Changes to the RUN mode.
Smart tuning button 	<ul style="list-style-type: none"> Held down for one second, held down for three seconds, held down for five seconds: Executes smart tuning according to the time the button is held down. 	<ul style="list-style-type: none"> Held down for one second, held down for three seconds, held down for five seconds: Executes smart tuning according to the time the button is held down. 	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING



SPECIFICATIONS

INDEX


SETTING TRANSITION CHARTS

Sensor Head

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS



Calculating Unit (used for connecting two or more Amplifier Units)



Installation


Important

Before connecting/disconnecting Smart Sensor components, make sure that the power to the Amplifier Unit is turned OFF. The Smart Sensor may malfunction if components are connected or removed while the power is ON.


Installing Sensor Heads

Installation Method

- Check the Sensor Head setting position by its emission center mark.
- Fix the sensor head in place with M3 screws. The screws must be tightened with a torque of 0.5 N•m.



- Be sure to attach the ferrite core accessory on the Sensor Head. Attach it within 100 mm of the Sensor Head side.



Important

- When mounting a Sensor Head, take care not to touch the emitter and receiver. Finger marks on the emitter and receiver may hinder correct measurements. If you have touched them by mistake, wipe them with a clean, soft cloth.
- Fix the connectors in places that are not subject to vibration or impact.

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX


SETTING
TRANSITION
CHARTS

Installing the Amplifier Unit

Amplifier Units can be easily mounted to 35-mm DIN Track.

Installation Method

Hook the connector end of the Sensor Head on the DIN Track, and press in at the bottom until the Amplifier Unit locks into place. If necessary, fix it in place by the End Plate.




Important

Hook the connector end of the Sensor Head on the DIN Track first. The mounting strength may decrease if the output cable end is hooked on the DIN Track first.

Removal Method


Push the Amplifier Unit and pull out from the connector end of the Sensor Head.



Connecting Calculating Units

Use a Calculating Unit to connect Amplifier Units when performing calculations between Amplifier Units and to prevent mutual interference between Sensor Heads.

The number of Amplifier Units that can be connected differs depending on the functions to be used.

Function	Number of Connectable Amplifier Units	See:
Calculation	Up to two units (Up to five units can be connected. However, calculations are done between pairs of two.) For (A-B) calculations 	(A-B) calculation: Page 45 Thickness calculation: Page 55
Mutual interference prevention	Up to five units	Page 84

For details on the connection method, see the next page.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS


TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS


Connection Method



- 1** **Open the connector cover on the Amplifier Unit.**
Open the connector cover by lifting and sliding it.
- 2** **Mount the Calculating Unit to the DIN Track.**
- 3** **Slide and connect the Calculating Unit to the Amplifier Unit connector.**
- 4** **Slide and connect the second Amplifier Unit to the Calculating Unit connector.**
- 5** **Fix in place with the End Plate (sold separately: PFP-M).**

Important

- To disconnect Amplifier Units and Calculating Units, perform the above operations in reverse order.
- The following diagram shows the channel numbers when multiple Amplifier Units are connected.



Connecting the Sensor Head to the Amplifier Unit


CONTENTS

Installation Method

INTRODUCTION

Align the position of the connector ⇨ mark with the ▲ mark on the Amplifier Unit, and insert the connector until it is locked in place.

PREPARATION FOR MEASUREMENT



FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection


Thickness

Positioning

Eccentricity and Surface Deflection

Removal Method

To disconnect the Sensor Head, hold the Sensor Head's connector ring and the Amplifier Unit connector, and then pull them straight out.



DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

Important

- Do not touch the terminals inside the connector.
- Prevent the connector from being subjected to static electricity.
- When the Sensor Head is replaced with a different type, set all the setting data inside the Amplifier Unit again since it will be cleared. **(default values: → See page 115.)**


Wiring Diagram

Wiring Input/Output Cables

The input/output cable has the following wires.

Important

Wire the cable correctly. Incorrect wiring may damage the Smart Sensor.



Cable color	Name	Function
Brown	Power supply	Connects the 10 to 30 VDC (including (p-p) 10% ripple) power supply. When using an Amplifier Unit with a PNP output, the power supply terminal is also the common I/O terminal for all I/O except for the analog output.
Blue	GND (0 V)	The GND terminal is the 0 V power supply terminal. When using an Amplifier Unit with an NPN output, the power supply terminal is also the common I/O terminal for all I/O except for the analog output.
White	HIGH judgement output	The HIGH judgement output outputs judgement results (HIGH).
Green	PASS judgment output	The PASS judgement output outputs judgement results (PASS).
Gray	LOW judgment output	The LOW judgement output outputs judgement results (LOW).
Yellow	Error output	This is output when the system detects an error. (For details on error messages, see page 122.)

Cable color	Name	Function
Black	Analog output	The analog output outputs a current or voltage in accordance with the measured value. (For details on setting method, see page 105.)
Shield	Analog GND (0 V)	The analog GND terminal is the 0 V terminal for the analog output. Important <ul style="list-style-type: none"> • Use the shield for analog output separately from the blue (0V) wire for power supply. • When analog output is not used, be sure to connect this wire to the blue (0 V) wire. • When using Calculating Units, make sure that the analog GND lines of the Amplifier Units are connected to each other.
Pink	LD-OFF input	If this LD-OFF input signal is ON, the laser will stop emission, causing a light intensity error. In this case, the analog output, digital display, judgement output, and judgement output display signals will be output according to the non-measurement settings. The sub-display will show <i>LdOFF</i> .
Orange	Zero reset input	The zero reset input is used to execute and cancel zero reset. (For details, see page 97.)
Purple	Timing input/ BANK input 0 (switched by external input setting)	Timing input: Signal input wire for obtaining hold function timing. While this input is being input, the sub-display will show <i>ETIMING</i> . BANK input 0: Signal input wire for bank switching. Banks are switched by ON/OFF combinations with BANK input 1. When connecting two or more Amplifier Units, use the CH1 Amplifier Unit for bank switching. The banks of the Amplifier Units of CH2 and later are switched together with CH1. (For details on switching and inputs, see page 112.)

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENTFLOW OF
OPERATIONBASIC
SETUPMAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
WarpageDouble
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
DeflectionDETAILED
SETTINGSTROUBLE-
SHOOTINGSPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

Cable color	Name	Function
Red	Reset input/BANK input 1 (switched by external input setting)	<p>Reset input:</p> <p>The reset input resets all measurement processing and outputs. While reset input is being input, the sub-display will show <i>RESET</i>. The analog and judgement output signals will be output according to the non-measurement settings. If this reset input switches ON while the hold function is used, the state in effect before the hold function was set will be restored.</p> <p>BANK input 1:</p> <p>Signal input wire for bank switching. Banks are switched by ON/OFF combinations with BANK input 0.</p> <p>When connecting two or more Amplifier Units, use the CH1 Amplifier Unit for bank switching. The banks of the Amplifier Units of CH2 and later are switched together with CH1.</p> <p>(For details on switching and inputs, see page 112.)</p>

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENTFLOW OF
OPERATIONBASIC
SETUPMAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
WarpageDouble
Sheet
Detection

Thickness

Positioning


Eccentricity
and Surface
DeflectionDETAILED
SETTINGSTROUBLE-
SHOOTINGSPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

I/O Circuit Diagrams

NPN Amplifier Unit



CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING


SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS

PNP Amplifier Unit



FLOW OF OPERATION

FLOW OF OPERATION

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

Preparation for Measurement

Installing the Sensor p. 23

Wiring Diagram p. 28


Setup

<Simple Measurement>



- Basic Setup p. 38

<Setting Up by 6 Measurement Contents>


- Measuring Height and Dimensions p. 40




- Measuring Steps and Warpage p. 45




- Detecting Double Sheet Detection p. 50




- Measuring Thickness and Insertion p. 55



- Positioning p. 64



- Detecting Eccentricity and Surface Deflection p. 70





Detailed Settings

- Smart Tuning (Optimizing the Sensing Conditions) p. 78
- Connecting Two or More Amplifier Units p. 82
- Mutual Interference Prevention p. 84
- Setting the Hysteresis p. 87
(Improving Unstable Measurement Near the Judgement Threshold)
- Setting Hold (Holding Measured Values Under Special Conditions) p. 89
- Bank Setting p. 95
- Zero Reset p. 97
- Scaling (Changing Digital Values for Specific Measured Values) p. 101
- Analog Output p. 105
- Output for Non-measurement p. 107
(Output Setting During Input of the Reset Signal at an Error)
- Timer p. 110
- External Input for Bank, Timing Input, Reset Input p. 112
- Key Lock Function p. 114
- Initializing Setting Data p. 115

When an Error Occurs

- Troubleshooting p. 120
- Error Messages p. 122
- Q&A p. 125

Engineering Data etc

- Function Transition Charts p. 144
- Specifications and Dimensions p. 128
- Timing Charts p. 133
- Engineering Data (Typical) p. 136

- Index p. 139

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

**FLOW OF
OPERATION**

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX


SETTING
TRANSITION
CHARTS

BASIC SETUP

BASIC SETUP

Default Settings	p.115
Initializing Settings	p.115
Setting Transition Charts	p.144

Display of RUN Mode








*1 The main display always shows the measured value.
 Default measured values are as follows:
 0 reference: Measurement center distance,
 + indication: NEAR side
 - indication: FAR side

* The numerals shown in the above diagram are an example only. The actual display may be different.

Simplest Setting

Smart Tuning (Single Smart Tuning)

Smart tuning sets optimum sensing conditions according to the operating conditions (response time and color/state of workpiece)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Set the reference workpiece in place, adjust the position of the Sensor Head while looking at the digital display values on the Amplifier Unit or the indicators on the Sensor Head so that the distance between the Sensor Head and the workpiece is the measurement center distance, and install the Sensor Head at this position.	
  Hold down for 1 second	Pressing down  Pressed down  Flashing	Press the  button for one second. When SMART SINGLE is displayed, release your finger from the button to start execution of smart tuning.	If "FAILED" flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again.


* To tune multiple workpieces or to tune workpieces having a different surface condition: **page 78**

MAIN APPLICATIONS & SETTING METHODS


Height	40
Steps and Warpage	45
Double Sheet Detection	50
Thickness	55
Positioning	64
Eccentricity and Surface Deflection	70

Height

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS



Procedure for setting up height



1 Sensor installation/wiring **Required**




Has the Sensor been installed and wired? (See page 23.)

Set the reference workpiece in place, adjust the position of the Sensor Head while looking at the digital display values on the Amplifier Unit or the indicators on the Sensor Head so that the height to be measured is near the measurement center distance, and install the Sensor Head at this position.

2 Set to the MENU mode **Required**











Select the desired mode to set the measurement conditions in.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>	<p>Lit MENU</p>	Hold down the button for three seconds to switch to the MENU mode.	
<p>Press to display.</p>		Press the button to display dETRI L.	* This operation is not required when hold and trigger conditions are not to be set.
<p>Press to display.</p>		Press the button to set the display to ON to set display of the detail menu.	

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 		Press the  button to apply the setting.	






3 Response time setting **Required**

Select the response time to match the size and moving speed of the sensing object.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display <i>SPEED</i> .	<div style="border: 1px solid black; padding: 5px; display: inline-block;">Default value: 500 ms</div>
 Press to select	 Select the desired value.	Press the  button to select the response time.	Select the response time to match the size and moving speed of the sensing object.  { 60 μ s, 120 μ s, 240 μ s, 500 μ s, 1 ms, 2 ms, 4 ms, 8 ms, 12 ms, 20 ms, 36 ms, 66 ms, 128 ms, 250 ms, 500 ms }
 		Press the  button to apply the setting.	* After the response time is changed, the smart tuning results are cleared, so be sure to re-execute tuning.

Smart tuning sets optimum sensing conditions according to the operating conditions (response time and color/state of workpiece)










4 Smart tuning **Required**

Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Check that the reference workpiece is set in place.	
  Hold down for 1 second	 ↓  Flashing	Press the  button for one second. When <i>SMART SINGLE</i> is displayed, release your finger from the button to start execution of smart tuning.	<div style="border: 1px dashed black; padding: 5px;"> If "FAILED" flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again. </div>

* To tune multiple workpieces or to tune workpieces having a different surface condition: **page 78**




5 Hold Optional

Set this item to hold measured values during the measurement period according to preset hold conditions.




















Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display <i>HOLD</i> .	Default value: OFF
 Press to select	 Select the desired value.	Press the  button to select the hold conditions.	<div style="border: 1px solid black; padding: 2px; display: inline-block;"><i>OFF</i></div> Hold OFF <div style="border: 1px solid black; padding: 2px; display: inline-block;"><i>AVE</i></div> The average measured value during the sampling period is held. <div style="border: 1px solid black; padding: 2px; display: inline-block;"><i>P E D P</i></div> The difference between the minimum and maximum values during the sampling period is held. <div style="border: 1px solid black; padding: 2px; display: inline-block;"><i>SAMPLE</i></div> The measured value at the start of the sampling period is held. <div style="border: 1px solid black; padding: 2px; display: inline-block;"><i>BOTTOM</i></div> The minimum value during the sampling period is held. <div style="border: 1px solid black; padding: 2px; display: inline-block;"><i>PEAK</i></div> The maximum value during the sampling period is held. (For details, see page 91.)
 		Press the  button to apply the setting. (When other than <i>OFF</i> is selected, proceed to "6 Trigger conditions," and when <i>OFF</i> is selected, proceed to "7 Threshold setting.")	* The clamp value is output until the first sampling period is finished. (For details on the clamp value, see page 107.)

6 Trigger conditions Optional

Set how timing of the hold measurement period is to be input.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display <i>TRIG</i> .	Default value: TIMING

CONTENTS
INTRODUCTION
PREPARATION FOR MEASUREMENT
FLOW OF OPERATION
BASIC SETUP
MAIN APPLICATIONS & SETTING METHODS
Height
Steps and Warpage
Double Sheet Detection
Thickness
Positioning
Eccentricity and Surface Deflection
DETAILED SETTINGS
TROUBLE-SHOOTING
SPECIFICATIONS
INDEX
SETTING TRANSITION CHARTS

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 <p>Press to select</p>	 <p>Select the desired value.</p>	Press the  button to select the trigger conditions.	<p>E1 MI NG</p> <p>Enter the trigger by using the timing input or by pressing the  button in the RUN mode. The period that the timing signal is ON is the sampling period.</p> <p>SELF-d</p> <p>The sampling period is the period that the measured value is lower than the specified self-trigger level.</p> <p>SELF-U</p> <p>The sampling period is the period that the measured value is greater than the specified self-trigger level. (For details, see page 93.)</p>
<p>SMART MENU/SET</p> 		Press the  button to apply the trigger conditions. (When SELF-U and SELF-d are selected, proceed to the next item, and when E1 MI NG is selected, proceed to "7 Threshold setting.")	
 <p>Press to display</p>		Press the  button to display SELF LV.	<div style="border: 1px solid black; padding: 2px;">Default value: 0.000</div>
		Press the  button to enable setting of the self-trigger level.	
<p>[Change numeric value] (How to)</p>  <p>Press to set.</p>	 <p>Set any value.</p>	Press the  button to move the digit, press the  button to change the numeric value, and set the self-trigger level.	<p>* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p>
<p>SMART MENU/SET</p> 		Press the  button to apply the setting.	

7 Threshold setting **Required**

Set the range of measured values to be judged as PASS by setting the HIGH and LOW thresholds.

CONTENTS	Button Operation	Display	Description of Operation	Explanation of Selection Menu
INTRODUCTION		Lit H L MENU	Press the button to display the HIGH threshold.	(Setting example) Non-defective product height 0 to 10 mm
PREPARATION FOR MEASUREMENT			Press the button to enable setting of the HIGH threshold.	
FLOW OF OPERATION			Press the button to enable setting of the HIGH threshold.	
BASIC SETUP	[Change numeric value] Press to set.		Press the button to move the digit, press the button to change the numeric value, and set the HIGH threshold. Set any value.	Set the MAX and MIN heights to be regarded as OK to the HIGH and LOW thresholds, respectively.
MAIN APPLICATIONS & SETTING METHODS	SMART MENU/SET 		Press the button to apply the setting.	* If the button is pressed when the cursor is at the right-most digit or the button is pressed when the cursor is at the left-most digit, the setting will be canceled.
Height		Lit H L MENU	Press the button to display the LOW threshold.	* Set so that the HIGH threshold is greater than the LOW threshold.
Steps and Warpage			Press the button to enable setting of the LOW threshold.	
Double Sheet Detection			Press the button to enable setting of the LOW threshold.	
Thickness	[Change numeric value] Press to set.		Press the button to move the digit, press the button to change the numeric value, and set the LOW threshold. Set any value.	
Positioning	SMART MENU/SET 		Press the button to apply the setting.	
Eccentricity and Surface Deflection				


8 Return to RUN mode **Required**

Switch to the mode in which measurement is performed.

CONTENTS	Button Operation	Display	Description of Operation	Explanation of Selection Menu
TROUBLE-SHOOTING	SMART MENU/SET Hold down for 3 seconds	H L Out MENU	Hold down the button for three seconds to switch to the RUN mode.	

* For details on optimizing settings, such as output and input, see "Detailed Settings." Example (Setting the reference height to 0 (or the offset value): **Zero Reset** → page 97.)


Steps and Warpage



Procedure for setting up steps and warpage

The Amplifier Units to set up differ depending on whether mutual interference prevention is set to ON or OFF.

Note that different channels are used to specify each menu item, as shown below.



ON: Mutual interference prevention is ON
OFF: Mutual interference prevention is OFF

1 Sensor installation/wiring **Required**

Has the Sensor been installed and wired? **(See page 23.)**

Connect two Amplifier Units with a Calculating Unit in between. (The calculation result is displayed and output on the CH2 Amplifier Unit.)

Set the reference workpiece in place, adjust the position of the Sensor Head while looking at the digital display values on the Amplifier Unit or the indicators on the Sensor Head so that each of the heights to be measured is near the measurement center distance, and install the Sensor Head at this position.

2 Set to the MENU mode **Required**

Select the desired mode to set the measurement conditions in.

(Use CH1 and CH2 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Hold down for 3 seconds	 Lit MENU	Hold down the button for three seconds to switch to the MENU mode.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection










DETAILED SETTINGS

TROUBLE-SHOOTING










SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS




Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display <i>DETAIL</i> .	
		Press the  button to set the display to <i>ON</i> to set display of the detail menu.	
 		Press the  button to apply the setting.	

3 Mutual interference prevention Optional Set this item to prevent the influence of mutual interference between two Sensor Heads. (Use CH1 for these settings.)








Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button on the CH1 Amplifier Unit to display <i>SYNC</i> .	Default value: OFF
		Press the  button to display <i>ON</i> .	
 		Press the  button to apply the setting.	* For details on the response time when connecting two or more Amplifier Units, see page 82.

4 Response time setting Required Select the response time to match the size and moving speed of the sensing object.

If mutual interference prevention is ON: Use CH1 for these settings.
 If mutual interference prevention is set to OFF: Use CH1 and CH2 for these settings.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display <i>SPEED</i> .	Default value: 500 ms






CONTENTS
INTRODUCTION
PREPARATION FOR MEASUREMENT
FLOW OF OPERATION
BASIC SETUP
MAIN APPLICATIONS & SETTING METHODS
Height
Steps and Warpage
Double Sheet Detection
Thickness
Positioning
Eccentricity and Surface Deflection
DETAILED SETTINGS
TROUBLE-SHOOTING
SPECIFICATIONS
INDEX
SETTING TRANSITION CHARTS

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to select	 Select the desired value.	Press the  button to select the response time.	Select the response time to match the size and moving speed of the sensing object.  { 60 μs, 120 μs, 240 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms, 12 ms, 20 ms, 36 ms, 66 ms, 128 ms, 250 ms, 500 ms }
 		Press the  button to apply the setting.	* After the response time is changed, the smart tuning results are cleared, so be sure to re-execute tuning.

5 Smart tuning **Required**

Smart tuning sets optimum sensing conditions according to the operating conditions (response time and color/state of workpiece)

If mutual interference prevention is ON: Use CH1 for these settings.
 If mutual interference prevention is set to OFF: Use CH1 and CH2 for these settings.











Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Check that the reference workpiece is set in place.	
  Hold down for 1 second	 ↓  Flashing	Press the  button for one second. When SMART SINGLE is displayed, release your finger from the button to start execution of smart tuning.	if "FAILED" flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again. * If mutual interference prevention is set to ON, after smart tuning execution for CH1 ends, it is also executed for the Amplifier Units of CH2 and later. If the tuning result is NG for either Amplifier Unit, the smart tuning setup results are not applied to any amplifier units.

* To tune multiple workpieces or to tune workpieces having a different surface condition: **page 78**

6 2-sensor operation (A-B) **Required**

Set this item when calculating the difference between the measurement results from two Sensor Heads.





(Use CH2 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button on the CH2 Amplifier Unit to display CALC .	 Calculating Unit CH1 CH2 (Calculation result is output.)
 Press to select		Press the  button to display A-b .	
 		Press the  button to apply the setting.	* For details on the response time when connecting two or more Amplifier Units, see page 82.

7 Threshold setting **Required**

Set the range of measured values to be judged as PASS by setting the HIGH and LOW thresholds.

(Use CH2 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button on the CH2 Amplifier Unit to display the HIGH threshold.	(Setting example) Non-defective product step 3 to 8 mm 
			Set the MAX and MIN steps to be regarded as OK to the HIGH and LOW thresholds, respectively.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the button to enable setting of the HIGH threshold.	<p>* If the button is pressed when the cursor is at the right-most digit or the button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p> <p>* Set so that the HIGH threshold is greater than the LOW threshold.</p>
<p>[Change numeric value]</p> <p>[Move digit]</p> <p>Press to set.</p>	Set any value.	Press the button to move the digit, press the button to change the numeric value, and set the HIGH threshold.	
		Press the button to apply the setting.	
 <p>Press to display</p>	Lit L MENU	Press the button to display the LOW threshold.	
		Press the button to enable setting of the LOW threshold.	
<p>[Change numeric value]</p> <p>[Move digit]</p> <p>Press to set.</p>	Set any value.	Press the button to move the digit, press the button to change the numeric value, and set the LOW threshold.	
		Press the button to apply the setting.	

8 Return to RUN mode **Required**

Switch to the mode in which measurement is performed.


(Use CH1 and CH2 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 <p>Hold down for 3 seconds</p>	Out MENU	Hold down the button for three seconds to switch to the RUN mode.	


* For details on optimizing settings, such as output and input, see "DETAILED SETTINGS."

Double Sheet Detection

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS



Procedure for setting up double sheet detection



1 Sensor installation/wiring **Required**



Has the Sensor been installed and wired? (See page 23.)

Set the reference workpiece in place, adjust the position of the Sensor Head while looking at the digital display values on the Amplifier Unit or the indicators on the Sensor Head so that the measured value at measurement of one product and at measurement of two products is within the measurement range, and install the Sensor Head at this position.

2 Set to the MENU mode **Required**

Select the desired mode to set the measurement conditions in.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>		Hold down the button for three seconds to switch to the MENU mode.	
<p>Press to display</p>		Press the button to display <i>dEtAl L</i> .	* This operation is not required when hold and trigger conditions are not to be set.
<p>Press to display.</p>		Press the button to set the display to <i>ON</i> to set display of the detail menu.	









Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to apply the setting.	

CONTENTS

3 Response time setting **Required**

Select the response time to match the size and moving speed of the sensing object.

INTRODUCTION

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display <i>SPEED</i> .	<div style="border: 1px solid black; padding: 5px; display: inline-block;">Default value: 500 ms</div>
	 <p>Select the desired value.</p>	Press the  button to select the response time.	Select the response time to match the size and moving speed of the sensing object. <div style="border: 1px solid black; padding: 5px; display: inline-block;"> <i>60MS</i> to <i>500MS</i> 60 μs, 120 μs, 240 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms, 12 ms, 20 ms, 36 ms, 66 ms, 128 ms, 250 ms, 500 ms </div>
		Press the  button to apply the setting.	* After the response time is changed, the smart tuning results are cleared, so be sure to re-execute tuning.

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection




Thickness

Positioning

Eccentricity and Surface Deflection

4 Smart tuning **Required**

Smart tuning sets optimum sensing conditions according to the operating conditions (response time and color/state of workpiece)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Check that the reference workpiece is set in place.	
		Press the  button for one second. When <i>SMART SINGLE</i> is displayed, release your finger from the button to start execution of smart tuning.	<div style="border: 1px dashed black; padding: 5px;"> If "<i>FAILED</i>" flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again. </div>

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS















INDEX

* To tune multiple workpieces or to tune workpieces having a different surface condition: **page 78**

SETTING TRANSITION CHARTS




5 Hold Optional




















Set this item to hold measured values during the measurement period according to preset hold conditions.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display <i>HOLD</i> .	<div style="border: 1px solid black; padding: 5px; display: inline-block;">Default value: OFF</div>
	 Select the desired value.	Press the  button to select the hold conditions.	<div style="display: flex; flex-direction: column; gap: 5px;"> <div> Hold OFF</div> <div> The average measured value during the sampling period is held.</div> <div> The difference between the minimum and maximum values during the sampling period is held.</div> <div> The measured value at the start of the sampling period is held.</div> <div> The minimum value during the sampling period is held.</div> <div> The maximum value during the sampling period is held. (For details, see page 91.)</div> </div>
		Press the  button to apply the setting. (When other than <i>OFF</i> is selected, proceed to "6 Trigger conditions," and when <i>OFF</i> is selected, proceed to "7 Threshold setting.")	* The clamp value is output until the first sampling period is finished. (For details on the clamp value, see page 107.)

6 Trigger conditions Optional

Set how timing of the hold measurement period is to be input.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display <i>TRIG</i> .	<div style="border: 1px solid black; padding: 5px; display: inline-block;">Default value: TIMING</div>

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 <p>Press to select</p>	 <p>Select the desired value.</p>	<p>Press the  button to select the trigger conditions.</p>	<p>E1 MI NG</p> <p>Enter the trigger by using the timing input or by pressing the  button in the RUN mode. The period that the timing signal is ON is the sampling period.</p> <p>SELF-d</p> <p>The sampling period is the period that the measured value is lower than the specified self-trigger level.</p> <p>SELF-U</p> <p>The sampling period is the period that the measured value is greater than the specified self-trigger level. (For details, see page 93.)</p>
<p>SMART MENU/SET</p> 		<p>Press the  button to apply the trigger conditions.</p> <p>(When SELF-U and SELF-d are selected, proceed to the next item, and when E1 MI NG is selected, proceed to "7 Threshold setting.")</p>	
 <p>Press to display</p>		<p>Press the  button to display SELF LV.</p>	<p>Default value: 0.000</p>
		<p>Press the  button to enable setting of the self-trigger level.</p>	
<p>[Change numeric value] [Move digit]</p>  <p>Press to set.</p>	 <p>Set any value.</p>	<p>Press the  button to move the digit, press the  button to change the numeric value, and set the self-trigger level.</p>	<p>* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p>
<p>SMART MENU/SET</p> 		<p>Press the  button to apply the setting.</p>	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING


























SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS




7 Threshold Setting **Required**

Set the range of measured values to be judged as **PASS** by setting the **HIGH** and **LOW** thresholds.

CONTENTS	Button Operation	Display	Description of Operation	Explanation of Selection Menu
INTRODUCTION	 Press to display		Press the  button to display the HIGH threshold.	(Examples) 
PREPARATION FOR MEASUREMENT			Press the  button to enable setting of the HIGH threshold.	Set the HIGH and LOW thresholds right in the middle of the measured values of sheets 1 and 2 and sheets 1 and 0, respectively.
FLOW OF OPERATION	 [Change numeric value] [Move opt.] Press to set.		Press the  button to move the digit, press the  button to change the numeric value, and set the HIGH threshold. Set any value.	
BASIC SETUP			Press the  button to apply the setting.	* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled. * Set so that the HIGH threshold is greater than the LOW threshold.
MAIN APPLICATIONS & SETTING METHODS	 Press to display		Press the  button to display the LOW threshold.	
Height			Press the  button to enable setting of the LOW threshold.	
Steps and Warpage	 [Change numeric value] [Move opt.] Press to set.		Press the  button to move the digit, press the  button to change the numeric value, and set the LOW threshold. Set any value.	
Double Sheet Detection			Press the  button to apply the setting.	


8 Return to RUN mode **Required**

Switch to the mode in which measurement is performed.

CONTENTS	Button Operation	Display	Description of Operation	Explanation of Selection Menu
TROUBLE-SHOOTING	 Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	


- * For details on optimizing settings, such as output and input, see "Detailed Settings." Example (Setting the reference height to 0 (or the offset value):
Zero Reset → page 97)

Thickness



Procedure for setting up thickness

The Amplifier Units to set up differ for each menu. Note also that different channels are used to specify each menu item, as shown below.



1 Sensor installation/wiring **Required**

Has the Sensor been installed and wired? (**See page 23.**)

Connect two Amplifier Units with a Calculating Unit in between. (The calculation result is displayed and output on the CH2 Amplifier Unit.)

Set up the two Sensor Heads so that they are facing each other, adjust the positions of the Sensor Heads while looking at the digital display values on the Amplifier Units or the indicators on the Sensor Heads so that the clearance between the sensing object and each Sensor Head is near the measurement center distance, and install the Sensor Heads at these positions.

Prepare a reference sensing object of known thickness.

2 Set to the MENU mode **Required**

Select the desired mode to set the measurement conditions in.

(Use CH1 and CH2 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Hold down for 3 seconds	 Lit MENU	Hold down the button for three seconds to switch to the MENU mode.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection










DETAILED SETTINGS

TROUBLE-SHOOTING










SPECIFICATIONS

INDEX




SETTING TRANSITION CHARTS








Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display <i>DETAIL</i> .	
 Press to display.		Press the  button to set the display to <i>ON</i> to set display of the detail menu.	
 		Press the  button to apply the setting.	

3 Mutual interference prevention **Required** Set this item to prevent the influence of mutual interference between two Sensor Heads. (Use CH1 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to all query.		Press the  button on the CH1 Amplifier Unit to display <i>SYNC</i> .	<div style="border: 1px solid black; padding: 2px;">Default value: OFF</div>
 Press to display.		Press the  button to display <i>ON</i> .	
 		Press the  button to apply the mutual interference prevention setting.	* For details on the response time when connecting two or more Amplifier Units, see page 82.

4 Response time setting **Required** Select the response time to match the size and moving speed of the sensing object. (Use CH1 for these settings.)






Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button on the CH1 Amplifier Unit to display <i>SPEED</i> .	<div style="border: 1px solid black; padding: 2px;">Default value: 500 ms</div>

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to select	 Select the desired value.	Press the  button to select the response time.	Select the response time to match the size and moving speed of the sensing object.  { 60 μ s, 120 μ s, 240 μ s, 500 μ s, 1 ms, 2 ms, 4 ms, 8 ms, 12 ms, 20 ms, 36 ms, 66 ms, 128 ms, 250 ms, 500 ms }
 		Press the  button to apply the setting.	* After the response time is changed, the smart tuning results are cleared, so be sure to re-execute tuning.

5 Smart tuning **Required**

Smart tuning sets optimum sensing conditions according to the operating conditions (response time and color/state of workpiece)

(Use CH1 for these settings.)






















Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Check that the reference workpiece is set in place.	
  Hold down for 1 second	Pressing down  ↓ Pressed down  Flashing	Press the  button on the CH1 Amplifier Unit for one second. When SMART/SINGLE is displayed, release your finger from the button to start execution of smart tuning.	If "FAILED" flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again. * After smart tuning execution for CH1 ends, it is also executed for the Amplifier Units of CH2 and later. If the tuning result is NG for either Amplifier Unit, the smart tuning setup results are not applied to any amplifier units.

* To tune multiple workpieces or to tune workpieces having a different surface condition: **page 78**

6 2-sensor operation (thickness) **Required**

Make this initial setting to measure thickness when using two Sensor Head to measure thickness.

(Use CH2 for these settings.)

CONTENTS	Button Operation	Display	Description of Operation	Explanation of Selection Menu
INTRODUCTION	—	—	Set the reference sensing object of which thickness is known in place.	
BASIC SETUP			Press the  button on the CH2 Amplifier Unit to display <i>CALC</i> .	
MAIN APPLICATIONS & SETTING METHODS			Press the  button to display <i>THICK</i> .	
Steps and Warpage			Press the  button to apply the thickness setting.	
Double Sheet Detection			Press the  button to enable setting of the thickness numeric value.	
Thickness			Press the  button to move the digit, press the  button to change the numeric value, and set the thickness numeric value.	
Positioning		Set any value.		<p>* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p>
DETAILED SETTINGS			Press the  button to apply the setting.	<p>* The 2-sensor operation reference value is determined based on the measured values of CH1 and 2 by the timing that setting of the thickness numeric values is executed.</p> <p>* For details on the response time when connecting two or more Amplifier Units, see page 82.</p>
TROUBLE-SHOOTING				
SPECIFICATIONS				
INDEX				
SETTING TRANSITION CHARTS				

Important

- If analog output is to be used, the entered thickness value is used as the center value of the analog output range. (For example, 0 V is used if the analog output is ± 5 V.)
- After thickness calculation, the maximum and minimum measurement range values (CH2 measurement values) are assigned as the maximum and minimum analog output range.
- Concerning the minimum and maximum analog output values, the analog output minimum value is output for the smaller of the post-thickness calculation values, and the analog output maximum value is output for the larger of these values.
- Example: If the ZX2-LD50 is used, a thickness value of 20 mm is entered, and analog output from -5 to 5 V is specified.

Measured Value After Thickness Calculation	How the Measurement Value Is Calculated	Analog Output
10.000	Thickness value $-$ (CH2 measurement range/2) = 20.000 $-$ 10.000	-5 V
20.000	Thickness value = 20.000	0 V
30.000	Thickness value $+$ (CH2 measurement range/2) = 20.000 $+$ 10.000	5 V

* The measurement range for the ZX2-LD50 is ± 10 mm.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS










INDEX

SETTING TRANSITION CHARTS

7 Hold Optional

Set this item to hold measured values during the measurement period according to preset hold conditions.
















(Use CH2 for these settings.)

CONTENTS	Button Operation	Display	Description of Operation	Explanation of Selection Menu									
INTRODUCTION	 Press to display.		Press the  button on the CH2 Amplifier Unit to display <i>HOLD</i> .	Default value: OFF									
PREPARATION FOR MEASUREMENT		 Press to select	 Select the desired value.	Press the  button to select the hold conditions.	<div style="border: 1px solid black; padding: 2px; display: inline-block;">OFF</div> Hold OFF <div style="border: 1px solid black; padding: 2px; display: inline-block;">AVE</div> The average measured value during the sampling period is held. <div style="border: 1px solid black; padding: 2px; display: inline-block;">P E O P</div> The difference between the minimum and maximum values during the sampling period is held. <div style="border: 1px solid black; padding: 2px; display: inline-block;">SAMPLE</div> The measured value at the start of the sampling period is held. <div style="border: 1px solid black; padding: 2px; display: inline-block;">BOTTOM</div> The minimum value during the sampling period is held. <div style="border: 1px solid black; padding: 2px; display: inline-block;">PEAK</div> The maximum value during the sampling period is held. (For details, see page 91.)								
FLOW OF OPERATION	BASIC SETUP		MAIN APPLICATIONS & SETTING METHODS	Height	Steps and Warpage	Double Sheet Detection	Thickness	Positioning	Eccentricity and Surface Deflection	DETAILED SETTINGS	TROUBLE-SHOOTING	SPECIFICATIONS	INDEX
	 		Press the  button to apply the setting. <div style="border: 1px solid black; padding: 10px; width: fit-content; margin: 10px auto;"> When other than <i>OFF</i> is selected, proceed to "7 Trigger conditions," and when <i>OFF</i> is selected, proceed to "9 Threshold setting." </div>	* The clamp value is output until the first sampling period is finished. (For details on the clamp value, see page 107.)									

8 Trigger conditions Optional

Set how timing of the hold measurement period is to be input.

(Use CH2 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button on the CH2 Amplifier Unit to display <i>ERI G</i> .	Default value: TIMING
 Press to select	 Select the desired value.	Press the  button to select the trigger conditions.	E I M I N G Enter the trigger by using the timing input or by pressing the  button in the RUN mode. The period that the timing signal is ON is the sampling period. SELF-d The sampling period is the period that the measured value is lower than the specified self-trigger level. SELF-U The sampling period is the period that the measured value is greater than the specified self-trigger level. (For details, see page 93.)
 		Press the  button to apply the trigger conditions. (When SELF-U and SELF-d are selected, proceed to the next item, and when E I M I N G is selected, proceed to "9 Threshold setting.")	
 Press to display		Press the  button to display <i>SELF LV</i> .	Default value: 0.000
		Press the  button to enable setting of the self-trigger level.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection










DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX




























SETTING TRANSITION CHARTS

Button Operation	Display	Description of Operation	Explanation of Selection Menu
[Change numeric value]  Press to set.	 Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the self-trigger level.	* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.
SMART  MENU/SET 		Press the  button to apply the setting.	

9 Threshold Setting **Required**

Set the range of measured values to be judged as PASS by setting the HIGH and LOW thresholds.







(Use CH2 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button on the CH2 Amplifier Unit to display the HIGH threshold.	(Setting example) Non-defective product thickness 3 to 8 mm
 Press to display.		Press the  button to enable setting of the HIGH threshold.	
[Change numeric value]  Press to set.	 Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the HIGH threshold.	Set the MAX and MIN thicknesses to be regarded as OK to the HIGH and LOW thresholds, respectively.
SMART  MENU/SET 		Press the  button to apply the setting.	* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.
 Press to display.		Press the  button to display the LOW threshold.	
 Press to display.		Press the  button to enable setting of the LOW threshold.	* Set so that the HIGH threshold is greater than the LOW threshold.
[Change numeric value]  Press to set.	 Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the LOW threshold.	
SMART  MENU/SET 		Press the  button to apply the setting.	

10 Return to RUN mode **Required**

Switch to the mode in which measurement is performed.

(Use CH1 and CH2 for these settings.)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 3 seconds	  	Hold down the  button for three seconds to switch to the RUN mode.	

* For details on optimizing settings, such as output and input, see "DETAILED SETTINGS."

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING


SPECIFICATIONS

INDEX


SETTING TRANSITION CHARTS

Positioning

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS



Procedure for setting up positioning



1 Sensor installation/wiring **Required**







Has the Sensor been installed and wired? (See page 23.)

Set the sensing object in place, adjust the position of the Sensor Head while looking at the digital display values on the Amplifier Unit or the indicators on the Sensor Head so that the upper and lower limits of the distance between the Sensor Head and the sensing object is within the measurement range, and install the Sensor Head at this position.

2 Set to the MENU mode **Required**











Select the desired mode to set the measurement conditions in.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>		Hold down the button for three seconds to switch to the MENU mode.	
<p>Press to display</p>		Press the button to display DETAIL.	* This operation is not required when scaling is not to be set.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to set the display to ON to set display of the detail menu.	
SMART  MENU/SET 		Press the  button to apply the setting.	






3 Response time setting **Required**

Select the response time to match the size and moving speed of the sensing object.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display SPEED .	Default value: 500 ms
 Press to select	 Select the desired value.	Press the  button to select the response time.	Select the response time to match the size and moving speed of the sensing object.  { 60 μ s, 120 μ s, 240 μ s, 500 μ s, 1 ms, 2 ms, 4 ms, 8 ms, 12 ms, 20 ms, 36 ms, 66 ms, 128 ms, 250 ms, 500 ms }
SMART  MENU/SET 		Press the  button to apply the setting.	* After the response time is changed, the smart tuning results are cleared, so be sure to re-execute tuning.

4 Smart tuning **Required**










Smart tuning sets optimum sensing conditions according to the operating conditions (response time and color/state of workpiece)

























Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Check that the reference workpiece is set in place.	
  Hold down for 1 second	 Pressed down  Flashing	Press the  button for one second. When <i>SMART SINGLE</i> is displayed, release your finger from the button to start execution of smart tuning.	<div style="border: 1px dashed black; padding: 5px;"> If " FAILED " flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again. </div>



* To tune multiple workpieces or to tune workpieces having a different surface condition: **page 78**

5 Scaling **Optional**

Set this item to change the display scale when you want to display a digital value on the Amplifier Unit different from the actual measured value. (e.g. to display the actual sensing distance)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display <i>SCALE</i> .	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> Default value: OFF </div>
 Press to display.		Press the  button to display <i>ON</i> .	
 		Press the  button to enable setting of scaling.	

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display S1-BEF.	<p><To display the actual sensing distance></p>  
		Press the  button to enable setting of S1-Before.	
[Change numeric value]  Press to set.	 [Numeric value before change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value before S1 is changed.	
		Press the  button to apply the numeric value of S1-Before.	
 Press to display.		Press the  button to display S1-AFT.	
		Press the  button to enable setting of S1-After.	
[Change numeric value]  Press to set.	 [Numeric value after change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value after S1 is changed.	
		Press the  button to apply the numeric value of S1-After.	

* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS


























TROUBLE-SHOOTING

SPECIFICATIONS

INDEX


























SETTING TRANSITION CHARTS

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display 52-bEF.	 <p>* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p>
		Press the  button to enable setting of S2-Before.	
 [Change numeric value] [Move digit] Press to set.	 [Numeric value before change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value before S2 is changed.	
 MENU/SET		Press the  button to apply the numeric value of S2-Before.	
 Press to display.		Press the  button to display 52-AFE.	
		Press the  button to enable setting of S2-After.	
 [Change numeric value] [Move digit] Press to set.	 [Numeric value after change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value after S2 is changed.	
 MENU/SET		Press the  button to apply the numeric value of S2-After.	




6 Threshold Setting **Required**

Set the range of measured values to be judged as PASS by setting the HIGH and LOW thresholds.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display the HIGH threshold.	(Setting example) Non-defective product position 49 to 51 mm
		Press the  button to enable setting of the HIGH threshold.	
[Change numeric value]  Press to set.		Press the  button to move the digit, press the  button to change the numeric value, and set the HIGH threshold.	Set the positioning MAX and MIN distances to the HIGH and LOW thresholds, respectively.
		Press the  button to apply the setting.	* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.
 Press to display.		Press the  button to display the LOW threshold.	
		Press the  button to enable setting of the LOW threshold.	* Set so that the HIGH threshold is greater than the LOW threshold.
[Change numeric value]  Press to set.		Press the  button to move the digit, press the  button to change the numeric value, and set the LOW threshold.	
		Press the  button to apply the setting.	

7 Return to RUN mode **Required**

Switch to the mode in which measurement is performed.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	

* For details on optimizing settings, such as output and input, see "DETAILED SETTINGS."

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING


SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

Eccentricity and Surface Deflection

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS



Procedure for setting up eccentricity and surface deflection


1 Sensor installation/wiring

2 Set to the MENU mode

3 Response time setting

4 Smart tuning

5 Scaling



1 Sensor installation/wiring **Required**




Has the Sensor been installed and wired? (See page 23.)

Set the sensing object in place, adjust the position of the Sensor Head while looking at the digital display values on the Amplifier Unit or the indicators on the Sensor Head so that the clearance between the Sensor Head and the sensing object is near the measurement center distance, and install the Sensor Head at this position.

2 Set to the MENU mode **Required**











Select the desired mode to set the measurement conditions in.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Hold down for 3 seconds		Hold down the button for three seconds to switch to the MENU mode.	
 Press to display		Press the button to display DETAIL L .	* This operation is not required when scaling, hold and trigger conditions are not to be set.
 Press to display.		Press the button to set the display to ON to set display of the detail menu.	

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 		Press the  button to apply the setting.	







3 Response time setting **Required**

Select the response time to match the size and moving speed of the sensing object.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button to display <i>SPEED</i> .	<div style="border: 1px solid black; padding: 5px; display: inline-block;">Default value: 500 ms</div>
 Press to select	 Select the desired value.	Press the  button to select the response time.	Select the response time to match the size and moving speed of the sensing object. <div style="border: 1px solid black; padding: 5px; display: inline-block;">  </div> { 60 μ s, 120 μ s, 240 μ s, 500 μ s, 1 ms, 2 ms, 4 ms, 8 ms, 12 ms, 20 ms, 36 ms, 66 ms, 128 ms, 250 ms, 500 ms }
 		Press the  button to apply the setting.	* After the response time is changed, the smart tuning results are cleared, so be sure to re-execute tuning.

4 Smart tuning **Required**

Smart tuning sets optimum sensing conditions according to the operating conditions (response time and color/state of workpiece)



































Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Check that the reference workpiece is set in place.	
  Hold down for 1 second	  Pressed down  Flashing	Press the  button for one second. When <i>SMART SINGLE</i> is displayed, release your finger from the button to start execution of smart tuning.	<div style="border: 1px dashed black; padding: 5px;"> If " <i>FAILED</i> " flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again. </div>


























* To tune multiple workpieces or to tune workpieces having a different surface condition: **page 78**

5 Scaling Optional

Set this item to change the display scale when you want to display a digital value on the Amplifier Unit different from the actual measured value. (e.g. to reverse the - and + indications)




- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS











Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button to display SCALE.	Default value: OFF
 Press to display.		Press the  button to display ON.	
		Press the  button to enable setting of scaling.	
 Press to display		Press the  button to display S1-BEF.	<p><To set the NEAR and FAR sides as - and + indications to the sensor:></p>   <p>* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p>
		Press the  button to enable setting of S1-Before.	
 [Change numeric value] Press to set.	 [Numeric value before change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value before S1 is changed.	
		Press the  button to apply the numeric value of S1-Before.	
 Press to display		Press the  button to display S1-AFT.	
		Press the  button to enable setting of S1-After.	
 [Change numeric value] Press to set.	 [Numeric value after change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value after S1 is changed.	
		Press the  button to apply the numeric value of S1-After.	

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display S2-BEF.	 <p>* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p>
		Press the  button to enable setting of S2-Before.	
[Change numeric value]  [Move digit]	 [Numeric value before change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value before S2 is changed.	
SMART MENU/SET 		Press the  button to apply the numeric value of S2-Before.	
		Press the  button to display S2-AFT.	
		Press the  button to enable setting of S2-After.	
[Change numeric value]  [Move digit]	 [Numeric value after change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value after S2 is changed.	
SMART MENU/SET 		Press the  button to apply the numeric value of S2-After.	

6 Hold Optional




Set this item to hold measured values during the measurement period according to preset hold conditions.




















Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display HOLD.	Default value: OFF

Button Operation	Display	Description of Operation	Explanation of Selection Menu
	 <p>Select the desired value.</p>	Press the  button to select the hold conditions.	 Hold OFF  The average measured value during the sampling period is held.  The difference between the minimum and maximum values during the sampling period is held.  The measured value at the start of the sampling period is held.  The minimum value during the sampling period is held.  The maximum value during the sampling period is held. (For details, see page 91.)
		Press the  button to apply the setting. (When other than OFF is selected, proceed to "7 Trigger conditions," and when OFF is selected, proceed to "8 Threshold setting.")	* The clamp value is output until the first sampling period is finished. (For details on the clamp value, see page 107.)

7 Trigger conditions Optional

Set how timing of the hold measurement period is to be input.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display TRIG.	<div style="border: 1px solid black; padding: 5px; display: inline-block;">Default value: TIMING</div>

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 <p>Press to select</p>	 <p>Select the desired value.</p>	Press the  button to select the trigger conditions.	<p>E1 MI NG</p> <p>Enter the trigger by using the timing input or by pressing the  button in the RUN mode. The period that the timing signal is ON is the sampling period.</p> <p>SELF-d</p> <p>The sampling period is the period that the measured value is lower than the specified self-trigger level.</p> <p>SELF-U</p> <p>The sampling period is the period that the measured value is greater than the specified self-trigger level. (For details, see page 93.)</p>
<p>SMART MENU/SET</p> 		<p>Press the  button to apply the trigger conditions.</p> <p>(When SELF-U and SELF-d are selected, proceed to the next item, and when E1 MI NG is selected, proceed to "8 Threshold setting.")</p>	
 <p>Press to display</p>		Press the  button to display SELF LV .	<p>Default value: 0.000</p>
		Press the  button to enable setting of the self-trigger level.	
<p>[Change numeric value]</p> <p>SMART MENU/SET</p> 	 <p>Set any value.</p>	Press the  button to move the digit, press the  button to change the numeric value, and set the self-trigger level.	<p>* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p>
<p>SMART MENU/SET</p> 		Press the  button to apply the setting.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

























SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS



8 Threshold Setting **Required**

Set the range of measured values to be judged as PASS by setting the HIGH and LOW thresholds.

CONTENTS	Button Operation	Display	Description of Operation	Explanation of Selection Menu
INTRODUCTION	 Press to display.	Lit H L MENU	Press the  button to display the HIGH threshold.	(Setting example) Non-defective product eccentricity -1 to 1 mm
PREPARATION FOR MEASUREMENT			Press the  button to enable setting of the HIGH threshold.	
FLOW OF OPERATION	[Change numeric value]  Press to set.		Press the  button to move the digit, press the  button to change the numeric value, and set the HIGH threshold.	
BASIC SETUP			Press the  button to apply the setting.	Set the eccentricity MAX and MIN distances to be regarded as OK to the HIGH and LOW thresholds, respectively. * If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled. * Set so that the HIGH threshold is greater than the LOW threshold.
MAIN APPLICATIONS & SETTING METHODS	 Press to display.	Lit H L MENU	Press the  button to display the LOW threshold.	
Height			Press the  button to enable setting of the LOW threshold.	
Steps and Warpage	[Change numeric value]  Press to set.		Press the  button to move the digit, press the  button to change the numeric value, and set the LOW threshold.	
Double Sheet Detection			Press the  button to apply the setting.	
Thickness				
Positioning				
Eccentricity and Surface Deflection				

9 Return to RUN mode **Required**

Switch to the mode in which measurement is performed.

CONTENTS	Button Operation	Display	Description of Operation	Explanation of Selection Menu
TROUBLE-SHOOTING	 Hold down for 3 seconds	H L Out MENU	Hold down the  button for three seconds to switch to the RUN mode.	
SPECIFICATIONS				
INDEX				

* For details on optimizing settings, such as output and input, see "DETAILED SETTINGS."

DETAILED SETTINGS

Smart Tuning (Optimizing the Sensing Conditions)	78
Connecting Two or More Amplifier Units	82
Mutual Interference Prevention	84
Setting the Hysteresis (Improving Unstable Measurement Near the Judgement Threshold)	87
Setting the Hold Function (Holding Measured Values Under Special Conditions)	89
Bank Setting	95
Zero Reset	97
Scaling (Changing Digital Values for Specific Measured Values)	101
Analog Output	105
Output for Non-measurement (Output Setting During Input of the Reset Signal at an Error)	107
Timer	110
External Input for Bank, Timing Input, Reset Input	112
Key Lock Function	114
Initializing Settings Data	115


Smart Tuning

Setting channels used when connecting multiple units
 If mutual interference prevention is ON: CH1
 If mutual interference prevention is set to OFF: Each CH


Smart tuning:

This setting option sets optimum sensing conditions according to the operating conditions (response time and color/state of workpiece).

Procedure for setting up smart tuning



* Steps 1, 2 and 4 are not required when the response time setting is completed since smart tuning can be performed even in the RUN mode.



Important

- When connecting two or more Amplifier Units and mutual interference prevention is set to ON, use the CH1 Amplifier Unit to execute tuning. After smart tuning execution for CH1 ends, it is also executed for the Amplifier Units of CH2 and later.

If the tuning result is NG for either Amplifier Unit, the smart tuning setup results are not applied to any amplifier units.








1 Set to the MENU mode Optional

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Hold down the button for three seconds to switch to the MENU mode.	

2 Response time setting Optional

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the button to display <i>SPEED</i> .	<div style="border: 1px solid black; padding: 5px; width: fit-content;">Default value: 500 ms</div>

CONTENTS
INTRODUCTION
PREPARATION FOR MEASUREMENT
FLOW OF OPERATION
BASIC SETUP
MAIN APPLICATIONS & SETTING METHODS
Height
Steps and Warpage
Double Sheet Detection
Thickness
Positioning
Eccentricity and Surface Deflection
DETAILED SETTINGS
TROUBLE-SHOOTING
SPECIFICATIONS
INDEX
SETTING TRANSITION CHARTS





Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to select	 Select the desired value.	Press the  button to select the response time.	Select the response time to match the size and moving speed of the sensing object.  { 60 μ s, 120 μ s, 240 μ s, 500 μ s, 1 ms, 2 ms, 4 ms, 8 ms, 12 ms, 20 ms, 36 ms, 66 ms, 128 ms, 250 ms, 500 ms }
 		Press the  button to apply the setting.	* After the response time is changed, the smart tuning results are cleared, so be sure to re-execute tuning.

3 Smart tuning **Required**









Select from one of the following three methods to execute smart tuning:

- (1) Tuning of a single stationary workpiece: Single smart tuning
- (2) Tuning of multiple stationary workpieces: Multi-smart tuning (a mix of workpieces having different color and state)
- (3) Tuning of workpieces having different surface states: Active smart tuning (execution of tuning while workpieces are moving)









(1) Tuning of a single stationary workpiece: Single smart tuning

Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Set the reference workpiece in place.	
  Hold down for 1 second	 Pressing down ↓ Pressed down Flashing	Press the  button for one second. When SMART SINGLE is displayed, release your finger from the button to start execution of smart tuning.	If "FAILED" flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again.





**(2) Tuning of multiple stationary workpieces: Multi-smart tuning
(a mix of workpieces having different color and state)**

Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Set reference workpiece 1 in place.	
 <p>Hold down for 3 seconds</p>	<p>Pressing down</p>  <p>↓</p> <p>Pressed down</p>  <p>Flashing</p>	<p>Press the  button for three seconds. When SMART / MULE1 is displayed, release your finger from the button to start execution of smart tuning.</p>	<p>* SMART / SINGLE is displayed for one to three seconds after the button is pressed, and then SMART / MULE1 is displayed.</p> <p>If "FAILED" flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again.</p>
—	—	Swap the workpiece with reference workpiece 2 and set it in place.	
 <p>Hold down for 3 seconds</p>	<p>Pressing down</p>  <p>↓</p> <p>Pressed down</p>  <p>Flashing</p>	<p>Press the  button for three seconds. When SMART / MULE1 is displayed, release your finger from the button to start execution of smart tuning.</p> <p>(When there are three or more reference workpieces, swap each workpiece and repeat the procedure.)</p>	<p>The optimum conditions are set for either reference workpiece 1 or 2 is set.</p> <p>* SMART / SINGLE is displayed for one to three seconds after the button is pressed, and then SMART / MULE1 is displayed.</p> <p>If you release your finger from the button SMART / SINGLE, the result of tuning workpiece 1 will not be reflected. If "FAILED" flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again.</p>

(3) Tuning of workpieces having different surface states: Active smart tuning (execution of tuning while workpieces are moving)

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 5 seconds	Pressing down  ↓ Pressed down  Flashing	Press the  button for five seconds with the workpiece set in place. When <i>SMART/ACTIVE</i> is displayed, release your finger from the button to start execution of smart tuning. [Because the execution of smart tuning continues, move the workpiece.]	* <i>SMART/SINGLE</i> and <i>SMART/MULTI</i> are displayed for one to five seconds after the button is pressed, and then <i>SMART/ACTIVE</i> is displayed.
  Hold down for 5 seconds		At the end of the desired tuning period, press the  button again for 5 to end tuning.	The optimum setting conditions will be set. If " FAILED " flashes on the sub-display for three seconds, it indicates that tuning was not possible. Change the response time setting to a larger value, and try again.

4 Return to RUN mode Optional

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS


INDEX

SETTING TRANSITION CHARTS

Connecting Two or More Amplifier Units

Use a Calculating Unit to connect Amplifier Units when performing calculations between Amplifier Units and to prevent mutual interference between Sensor Heads.

The number of Amplifier Units that can be connected differs depending on the functions to be used.

Function	Number of Connectable Amplifier Units	See:
Calculation	Up to two units (Up to five units can be connected. However, calculations are done between pairs of two.) For (A-B) calculations 	(A-B) calculation: Page 45 Thickness calculation: Page 55
Mutual interference prevention	Up to five units	Page 84

Important

- Supply power to all connected Amplifier Units at the same time.
- When connecting two or more Amplifier Units, the response times (maximum values) are as follows:

Mutual Interference Prevention	Two-Sensor Operation	Total Response Time
OFF	OFF	Response time setting for each CH
	(A - B), THICK	(Total response time setting for each CH) + (4 ms × number of connected units)
ON	OFF	(Response time per unit in the table below) × number of connected units
	(A - B), THICK	

<Response time if mutual interference prevention is set to ON>

CH1 Response Time Setting	Response Time per Unit
60 μs	3 ms
120 μs	3 ms
240 μs	3 ms
500 μs	4 ms
1 ms	8 ms
2 ms	16 ms
4 ms	32 ms
8 ms	64 ms
12 ms	72 ms
20 ms	80 ms
36 ms	100 ms
66 ms	160 ms
128 ms	280 ms
250 ms	520 ms
500 ms	1 s

The displayed and set up menus differ depending on the channel when two or more Amplifier Units are connected and when mutual interference prevention is set to ON.

Use the Amplifier Units of the corresponding channel numbers to specify settings by referring to the tables below.

<Menus and setting channels when two or more Amplifier Units are connected>

Menu	CHs Used to Specify Settings	CHs Not Used to Specify Settings	Notes
Mutual interference prevention <i>SYNC</i>	CH1	CH2 to CH5: These cannot be used. (The setting menu is not displayed on the digital display.)	The setting of CH1 is also applied to Amplifier Units of CH2 and later.
Two-sensor operation setting <i>SCALE</i> Thickness setting <i>THICK</i>	CH2 to CH5	CH1: This cannot be used. (The setting menu is not displayed on the digital display.)	
Bank switching setting <i>BANK</i>	CH1	CH2 to CH5: These cannot be used. (The setting menu is not displayed on the digital display.)	<ul style="list-style-type: none"> The Amplifier Units of CH2 and later are switched together with CH1. (Bank registration is possible for individual amplifier units.) Also use CH1 to switch the banks by means of an external input.
Initialization <i>INIT</i>	CH1	CH2 to CH5: These cannot be used. (The setting menu is not displayed on the digital display.)	The Amplifier Units of CH2 and later are initialized together with CH1.

<Menus and setting channels when mutual interference prevention is set to ON>

Menu	CHs Used to Specify Settings	CHs Not Used to Specify Settings	Notes
Response time setting <i>SPEED</i>	CH1	CH2 to CH5: These cannot be used. (The setting menu is not displayed on the digital display.)	The setting of CH1 is also applied to Amplifier Units of CH2 and later.
Smart tuning	CH1	CH2 to CH5: Smart tuning cannot be executed for these separately.	Smart tuning for the Amplifier Units of CH2 and later are executed together with CH1.

(For details on the setup procedure when mutual interference prevention is set to ON, see the next page.)


Mutual Interference Prevention Setting channel: CH1

Mutual interference prevention:

This refers to the function for preventing the influence of Sensor Heads when mounted close to each other. (This function can be used for up to five Amplifier Units connected by using Calculating Units (ZX2-CAL).)

Procedure for setting up mutual interference prevention

- 1 Set to the MENU mode
 - 2 Mutual interference prevention setting
 - 3 Return to RUN mode
- Setting completed











1 Set to the MENU mode




Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>		Hold down the button of the CH1 Amplifier Unit for three seconds to switch to the MENU mode.	
<p>Press to display</p>		Press the button to display <i>DETAIL L</i> .	* This step is not required if detail menu display is already set to ON in the MENU mode.
<p>Press to display</p>		Press the button to set the display to <i>ON</i> to set display of the detail menu.	
		Press the button to apply the setting.	

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS

2 Mutual interference prevention setting

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display SYNC.	Default value: OFF
		Press the  button to display ON.	
		Press the  button to apply the setting.	

3 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Hold down the  button for three seconds to switch to the RUN mode.	

Important

- When CH1 is used to specify a setting while mutual interference prevention is set to ON, the menus for which the same setting is applied to the Amplifier Units of CH2 and later are shown in the following table.

Specify settings for the menus in the following table after setting mutual interference prevention to ON.

Menu	Displayable and Specifiable CH Number	Notes
Response time setting <i>SPEED</i>	CH1	The setting of CH1 is also applied to Amplifier Units of CH2 and later.
Smart tuning	CH1	Smart tuning for the Amplifier Units of CH2 and later are executed together with CH1.

- When connecting two or more Amplifier Units, the response times (maximum values) are as follows:

Mutual Interference Prevention	Two-Sensor Operation	Total Response Time
OFF	OFF	Response time setting for each CH
	(A – B), THICK	(Total response time setting for each CH) + (4 ms × number of connected units)
ON	OFF	(Response time per unit in the table below) × number of connected units
	(A – B), THICK	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

<Response time if mutual interference prevention is set to ON>

CH1 Response Time Setting	Response Time per Unit
60 μ s	3 ms
120 μ s	3 ms
240 μ s	3 ms
500 μ s	4 ms
1 ms	8 ms
2 ms	16 ms
4 ms	32 ms
8 ms	64 ms
12 ms	72 ms
20 ms	80 ms
36 ms	100 ms
66 ms	160 ms
128 ms	280 ms
250 ms	520 ms
500 ms	1 s

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX


SETTING TRANSITION CHARTS

Setting the Hysteresis

Setting channels used when connecting multiple units: Each CH

Hysteresis width:

This refers to the difference between the operation point and return point. Set the hysteresis width for the upper and lower limits of the judgements if the HIGH, PASS or LOW judgement is unstable near the threshold values.



Procedure for setting up the hysteresis width

- 1 Set to the MENU mode
 - 2 Hysteresis width setting
 - 3 Return to RUN mode
- Setting completed

1 Set to the MENU mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>		Hold down the button for three seconds to switch to the MENU mode.	
<p>Press to display.</p>		Press the button to display DETAIL L .	* This step is not required if detail menu display is already set to ON in the MENU mode.
<p>Press to display.</p>		Press the button to set the display to ON to set display of the detail menu.	
		Press the button to apply the setting.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS















TROUBLE-SHOOTING

SPECIFICATIONS





INDEX

SETTING TRANSITION CHARTS

2 Hysteresis width setting

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button to display <i>HYS</i> .	Default value: 0.000
 Press to display.		Press the  button to enable setting of the hysteresis width.	
[Change numeric value] [Move right]  Press to set.	 Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the hysteresis width.	* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.
 		Press the  button to apply the setting.	

3 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	

Important

- The hysteresis width for HIGH, PASS or LOW judgment is disabled when the hold function is enabled.
- The hysteresis width is enabled when the self-trigger is set.


Setting the Hold Function

Setting channels used when connecting multiple units: Each CH 1

Hold:

The hold function holds any values during the measurement period, and outputs these values at the end of measurement.

Procedure for setting up hold



1 Set to the MENU mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>		Hold down the button for three seconds to switch to the MENU mode.	
<p>Press to display.</p>		Press the button to display <i>dETAL L</i> .	* This step is not required if detail menu display is already set to ON in the MENU mode.
<p>Press to display.</p>		Press the button to set the display to <i>ON</i> to set display of the detail menu.	
		Press the button to apply the setting.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING
















SPECIFICATIONS











INDEX

SETTING TRANSITION CHARTS

2 Hold conditions setting

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 <p style="font-size: small; text-align: center;">Press to display</p>		Press the  button to display <i>HOLD</i> .	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Default value: OFF</div>
 <p style="font-size: small; text-align: center;">Press to select</p>	 <p style="text-align: center;">Select the desired value.</p>	Press the  button to select the hold conditions.	<div style="margin-bottom: 5px;"> Hold OFF</div> <div style="margin-bottom: 5px;"> The average measured value during the sampling period is held.</div> <div style="margin-bottom: 5px;"> The difference between the minimum and maximum values during the sampling period is held.</div> <div style="margin-bottom: 5px;"> The measured value at the start of the sampling period is held.</div> <div style="margin-bottom: 5px;"> The minimum value during the sampling period is held.</div> <div style="margin-bottom: 5px;"> The maximum value during the sampling period is held. (For details, see the following page.)</div>
 		Press the  button to apply the setting. <div style="border-left: 1px solid black; border-right: 1px solid black; padding: 5px; display: inline-block;"> When other than <i>OFF</i> is selected, proceed to "3 Self-trigger setting." </div>	* The clamp value is output until the first sampling period is finished. (For details on the clamp value, see page 107.)

Selection menu	Details
OFF (default)	<p>Hold measurement is not performed. The measured value is output at all times.</p>
	<p>The average measured value during the sampling period is held. The output changes at the end of the sampling period and is held until the end of the next sampling period.</p> 
	<p>The difference between the minimum and maximum values during the sampling period is held. This option is selected mainly to detect vibration. The output changes at the end of the sampling period and is held until the end of the next sampling period.</p> 
	<p>The measured value at the start of the sampling period is held. The output changes at the end of the sampling period and is held until the end of the next sampling period.</p> 
	<p>The minimum value during the sampling period is held. The output changes at the end of the sampling period and is held until the end of the next sampling period.</p> 
	<p>The maximum value during the sampling period is held. The output changes at the end of the sampling period and is held until the end of the next sampling period.</p> 

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS











TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

3 Self-trigger setting

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 <small>Press to display</small>		Press the  button to display <i>TRIG</i> .	<div style="border: 1px solid black; padding: 5px; display: inline-block;">Default value: TIMING</div>
 <small>Press to select</small>	 Select the desired value.	Press the  button to select the self-trigger.	ELIMING Enter the trigger by using the timing input or by pressing the  button in the RUN mode. The period that the timing signal is ON is the sampling period. SELF-d The sampling period is the period that the measured value is lower than the specified self-trigger level. SELF-U The sampling period is the period that the measured value is greater than the specified self-trigger level. (For details, see the following page.)
<small>SMART</small>  <small>MENU/SET</small> 		Press the  button to apply the self-trigger.	
		<div style="border: 1px solid black; padding: 10px; display: inline-block;"> When <i>SELF-U</i> and <i>SELF-d</i> are selected, proceed to the next item, and when <i>ELIMING</i> is selected, proceed to "5 Return to RUN mode." </div>	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection








DETAILED SETTINGS

TROUBLE-SHOOTING












SPECIFICATIONS




INDEX

SETTING TRANSITION CHARTS







Selection menu	Details
 (Default)	Either input the timing signal from an external device, or enter the trigger for starting sampling by pressing the  button. The period that the timing signal is ON is the sampling period.  (For details on external inputs, see page 112.)
	The sampling period is the period that the measured value is lower than the specified self-trigger level. Hold measurement is possible without a sync input. 
	The sampling period is the period that the measured value is greater than the specified self-trigger level. Hold measurement is possible without a sync input. 

4 Trigger level setting

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button to display SELFLV.	Default value: 0.000
		Press the  button to enable setting of the self-trigger level.	
[Change numeric value] [Move digit]  Press to set.	 Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the self-trigger level.	* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 		Press the  button to apply the setting.	

5 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  <p>Hold down for 3 seconds</p>	  	Hold down the  button for three seconds to switch to the RUN mode.	

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS


Bank Setting

Setting channels used when connecting multiple units
 Bank switching: CH1
 Bank registration: Each CH

Bank setting:

Up to four sets of settings can be stored in memory. (Default: bank 0) This is recommended, for example, when measuring on multi-lot lines.

Procedure for setting up banks



The following menu settings can be registered to banks:

HIGH threshold
LOW threshold
Response time
Hysteresis width
Measured value display scaling
Pre-scaling display value 1
Post-scaling display value 1
Pre-scaling display value 2
Post-scaling display value 2
Self-trigger level

Important

- When connecting two or more Amplifier Units, use the CH1 Amplifier Unit for switching. The Amplifier Units of CH2 and later are switched together with CH1.

1 Set to the MENU mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>		Hold down the button for three seconds to switch to the MENU mode.	
<p>Press to touch</p>		Press the button to display <i>dEtail L</i> .	* This step is not required if detail menu display is already set to ON in the MENU mode.
<p>Press to display.</p>		Press the button to set the display to <i>ON</i> to set display of the detail menu.	
		Press the button to apply the setting.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS









TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

2 Bank switching




Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Press the  button to display BANK .	<div style="border: 1px solid black; padding: 2px;">Default value: 0</div>
	 Select the desired value.	Press the  button to select the bank.	<div style="border: 1px solid black; padding: 2px;">0 to 3</div>
		Press the  button to apply the setting.	

3 Various settings

Set the various menu items that require setting.

Execute smart tuning for each bank to be used because the smart tuning results are not applied to other banks.

4 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
		Hold down the  button for three seconds to switch to the RUN mode.	

The following explains how to switch banks and perform measurement.

Either switch banks by following the steps 1 → 2 → 4 described above, or input the required signal from an external device to switch the bank.


(For details on external inputs, see page 112.)

Zero reset:


This refers to setting the reference value to "0" or any desired numeric value so that the measured value can be displayed and output as a positive or negative deviation (tolerance) from the reference value. The measured value can be set to "0" or any desired numeric value at any timing in the RUN mode.

(Examples)


■ To eliminate reference deviation




■ To measure steps in a sensing object (Executing a zero reset at each measurement)



■ To display the height of a workpiece



■ To display the actual measuring distance value



CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS















INDEX

SETTING TRANSITION CHARTS

Procedure for setting up zero reset









- 1 Set to the MENU mode
 - 2 Zero reset memory setting
 - 3 Display setting at zero reset
 - 4 Return to RUN mode
 - 5 Zero reset execution
- Setting completed

1 Set to the MENU mode




Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 3 seconds	 	Hold down the  button for three seconds to switch to the MENU mode.	
 Press to display		Press the  button to display <i>dETAIL L</i> .	* This step is not required if detail menu display is already set to ON in the MENU mode.
 Press to display.		Press the  button to set the display to <i>ON</i> to set display of the detail menu.	
 		Press the  button to apply the setting.	

2 Zero reset memory setting

Select whether or not to hold the measured value after the zero reset was performed when the power is turned OFF.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display <i>ZRMEM</i> .	Default value: OFF
 Press to select	 Select the desired value.	Press the  button to select the zero reset memory setting.	 Saves the current measured result.  Does not save the current measured result. When executing a zero reset at each measurement, set to <i>OFF</i> .

CONTENTS
INTRODUCTION
PREPARATION FOR MEASUREMENT
FLOW OF OPERATION
BASIC SETUP
MAIN APPLICATIONS & SETTING METHODS
Height
Steps and Warpage
Double Sheet Detection
Thickness
Positioning
Eccentricity and Surface Deflection
DETAILED SETTINGS
TROUBLE-SHOOTING
SPECIFICATIONS
INDEX
SETTING TRANSITION CHARTS















Button Operation	Display	Description of Operation	Explanation of Selection Menu
 		Press the  button to apply the setting.	

Important





- If zero reset memory is set to [ON], the zero reset level will be written in the Amplifier Unit's non-volatile memory (EEPROM) each time a zero reset is executed. The EEPROM can be written a maximum of 100,000 times. Writing the zero reset level for each measurement can, therefore, use up the life of the memory and lead to malfunctions.
- Even if zero reset memory is set to [OFF] and disabled, the zero reset level also will be saved if thresholds or other functions have been changed. Zero reset is retained after startup when these functions have been changed.

3 Display setting at zero reset

Set the zero reset memory function to set the reference value to any numeric value.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button to display ZR.dl SP.	<div style="border: 1px solid black; padding: 2px;">Default value: 0.000</div>
		Press the  button to enable setting of values at a reset.	
(Change numeric value)  Press to set.	 Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the offset level.	* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.
 		Press the  button to apply the setting.	

4 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	

5 Zero reset execution

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection




DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX




SETTING TRANSITION CHARTS

Button Operation	Display	Description of Operation	Explanation of Selection Menu
—	—	Set the sensing object to be used for executing the zero reset.	
 Hold both down for 1 second		Either press the  button for one second in the RUN mode, or input the zero reset signal (4 ms to 1 s) from an external device.	(For details on external inputs, see page 112.)

Important

- The minimum display value is -99.999, and the maximum display value is 999.999. If the measured value is below the minimum value after execution of zero reset, -99.999 will be displayed. 999.999 will be displayed if the measured value is above the maximum value. Zero reset can be executed only if the measured value is within $\pm 10\%$ of the rated measurement range.
- Even if a zero reset is executed, the threshold does not change from the setting before execution of the zero reset.
(For example, even if a zero reset is executed so that measured value 2 become 0, the HIGH threshold stays at 5 if it is 5 before zero reset is executed.)


Procedure for canceling a zero reset

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Hold both down for 1 second		Either press the  button for one second in the RUN mode, or input the zero reset signal (3 s or more) from an external device.	

Scaling:

The display scale can be changed when you want to display a digital value on the Amplifier Unit different from the actual measured value. (For example, when you want to set the measured value as the actual measuring distance.)

Procedure for setting up scaling



































1 Set to the MENU mode



Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Hold down for 3 seconds		Hold down the button for three seconds to switch to the MENU mode.	
 Press to display		Press the button to display <i>DETAIL L</i> .	* This step is not required if detail menu display is already set to ON in the MENU mode.
 Press to display.		Press the button to set the display to <i>ON</i> to set display of the detail menu.	
		Press the button to apply the setting.	


























2 Scaling

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the button to display <i>SCALE</i> .	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Default value: OFF</div>





- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display ON.	
 		Press the  button to enable setting of scaling.	
 Press to display.		Press the  button to display S1-BEF.	<p><To display the actual sensing distance></p>  
		Press the  button to enable setting of S1-Before.	
 [Change numeric value] [Move left] Press to set.	 [Numeric value before change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value before S1 is changed.	
 		Press the  button to apply the numeric value of S1-Before.	
 Press to display.		Press the  button to display S1-AFT.	
		Press the  button to enable setting of S1-After.	
 [Change numeric value] [Move right] Press to set.	 [Numeric value after change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value after S1 is changed.	
 		Press the  button to apply the numeric value of S1-After.	

* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display.		Press the  button to display S2-bEF.	 <p>* If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.</p>
		Press the  button to enable setting of S2-Before.	
[Change numeric value] [Move digit] Press to set.	 [Numeric value before change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value before S2 is changed.	
SMART MENU/SET  		Press the  button to apply the numeric value of S2-Before.	
 Press to display.		Press the  button to display S2-AFT.	
		Press the  button to enable setting of S2-After.	
[Change numeric value] [Move digit] Press to set.	 [Numeric value after change] Set any value.	Press the  button to move the digit, press the  button to change the numeric value, and set the measured value after S2 is changed.	
SMART MENU/SET  		Press the  button to apply the numeric value of S2-After.	

3 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
SMART MENU/SET   Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS


Important

- Analog output when specifying the scaling setting

The analog output range is assigned based on the post-scaling display value setting range (between S1-AFT and S2-AFT).

Concerning the minimum and maximum analog output values, the analog output minimum value is output for the smaller of the post-scaling display values (S1-AFT/S2-AFT), and the analog output maximum value is output for the larger of these values.

Example) To set the analog output in the range of -5 V to 5 V and display a value from 45 mm to 55 mm when using the ZX2-LD50(L) at a distance of 45 mm to 55 mm from the sensor:



- (1) Select -5 , 5 as the analog output setting.
- (2) Specify the AFT value, and then assign the display value based on the measured value. Assign the analog output range based on the display value range.

- S1-BEF: -5 (mm)
- S1-AFT: 55 (mm)
- S2-BEF: 5 (mm)
- S2-AFT: 45 (mm)

<Initial setting>

Display value	Analog output
-10 mm	-5 V
10 mm	5 V



<Scaling setting>

Scaling point	Pre-scaling display value (BEF)	Post-scaling display value (AFT)	Analog output
S1	-5 mm	55 mm	5 V
S2	5 mm	45 mm	-5 V

- Threshold value when specifying the scaling setting

Even if scaling is executed, the threshold does not change from the setting before execution of scaling. (For example, the HIGH threshold stays at 5 if it was 5 before scaling is executed.)

Analog Output


Setting channels used when connecting multiple units: Each CH

Analog output:

This refers to the conversion of measurement results to 4 to 20 mA current output or to -5 to +5 V/1 to 5 V voltage output.

The relationship between display values and analog output values can be freely specified. (Monitor focus)

Procedure for setting up analog output



1 Set to the MENU mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>	<p>Lit MENU</p>	Hold down the button for three seconds to switch to the MENU mode.	

2 Analog output setting

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Press to display.</p>		Press the button to display A-OUT.	Default value: -5 to +5 V
<p>Press to select</p>	<p>Select the desired value.</p>	Press the button to select analog output.	Current output 4 to 20 mA Voltage output 1 to 5 V Voltage output 5 to +5 V
		Press the button to apply the setting.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS




TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

3 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	

Freely specifying the relationship between display values and analog output values (equivalent to the former ZX-L-N monitor focus)


- To specify any analog output value for a display value, assign the analog output range and the minimum and maximum analog output values by selecting the analog output and then setting up scaling.
(If scaling is not set up, the measurement range is the same as the analog output range.)

The analog output range is assigned based on the post-scaling display value setting range (between S1-AFT and S2-AFT).

Concerning the minimum and maximum analog output values, the analog output minimum value is output for the smaller of the post-scaling display values (S1-AFT/S2-AFT), and the analog output maximum value is output for the larger of these values.

- To only specify the analog output range, without changing display values

Example) To set the analog output in the range of -5 V to 5 V when using the ZX2-LD50(L) at a distance of 45 mm to 55 mm from the sensor:



- Select -5 , 5 V as the analog output setting.
- Specify the measurement range to use for the BEF and AFT values, and then assign the analog output range based on the measured value range.

- S1-BEF: -5 (mm)
- S1-AFT: -5 (mm) → Set the same value as S1-BEF
- S2-BEF: 5 (mm)
- S2-AFT: 5 (mm) → Set the same value as S2-BEF

<Initial setting>

Display value	Analog output
-10 mm	-5 V
10 mm	5 V

<Scaling setting>

Scaling point	Pre-scaling display value (BEF)	Post-scaling display value (AFT)	Analog output
S1	-5 mm	-5 mm	-5 V
S2	5 mm	5 mm	5 V

- To specify the analog output range after changing display values
(For details on scaling, see page 104.)

Output for Non-measurement

Setting channels used when connecting multiple units: Each CH 1


Output for non-measurement:

This refers to specifying the output contents when an error occurs (Error-dark or Error-bright), when a reset is being input, or before measured values are finalized.

(For details on these errors, see page 122.)

Selection Menu	Output Contents	
	Judgment Output	Analog Output
KEEP (Default)	The measurement value immediately before the non-measurement state is entered is held and output.	
CLAMP	All OFF	<p>The specified CLAMP value is output. The following options are available.</p> <ul style="list-style-type: none"> For voltage output: -5.00 to 5.00 V (in 1-V steps), or the maximum (approximately 5.5 V) For current output: 4.00 to 20.00 mA (in 1-mA steps), or the maximum (approximately 22 mA)

Procedure for setting up output for non-measurement



1 Set to the MENU mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>		Hold down the button for three seconds to switch to the MENU mode.	
<p>Press to display.</p>		Press the button to display DETAIL L.	* This step is not required if detail menu display is already set to ON in the MENU mode.
<p>Press to display.</p>		Press the button to set the display to ON to set display of the detail menu.	
		Press the button to apply the setting.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS










TROUBLE-SHOOTING

SPECIFICATIONS
















INDEX

SETTING TRANSITION CHARTS







2 Output settings for non-measurement

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button to display <i>RStOUT</i> .	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Default value: KEEP</div>
 Press to select	 Select the desired value.	Press the  button to select output for non-measurement.	<div style="border: 1px solid black; padding: 2px; display: inline-block;">KEEP</div> The measured value status before measurement is stopped is held and output.
 		Press the  button to apply the setting.	<div style="border: 1px solid black; padding: 2px; display: inline-block;">CLAMP</div> Judgment output: All OFF Analog output: The preset clamp value is output.

3 Clamp value setting

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button to display <i>CLAMP</i> .	<div style="border: 1px solid black; padding: 2px; display: inline-block;">Default value: MAX</div>
 Press to select	 Select the desired value.	Press the  button to display the clamp value.	For voltage output:  to  In 1 V units 
			For current output:  to  In 1 mA units 
 		Press the  button to apply the setting.	

4 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 3 seconds	  	Hold down the  button for three seconds to switch to the RUN mode.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS


INDEX

SETTING TRANSITION CHARTS

Timer:

The timing for judgement outputs can be adjusted to match the operation of external devices.

Procedure for setting up the timer
















1 Set to the MENU mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Hold down for 3 seconds		Hold down the button for three seconds to switch to the MENU mode.	
 Press to display		Press the button to display <i>detail L</i> .	* This step is not required if detail menu display is already set to ON in the MENU mode.
 Press to display.		Press the button to set the display to <i>ON</i> to set display of the detail menu.	
		Press the button to apply the setting.	





2 Timer setting

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display	 Select the desired value.	Press the button to display <i>ONELM</i> when setting the ON-delay and <i>OFFELM</i> when setting the OFF-delay.	 ON-delay timer OFF-delay timer (For details, see the following page.)
		Press the button to enable setting of the timer.	

Button Operation	Display	Description of Operation	Explanation of Selection Menu
[Change numeric value]  Press to set.		Press the  button to move the digit, press the  button to change the numeric value, and set the time set to the timer.	 * If the  button is pressed when the cursor is at the right-most digit or the  button is pressed when the cursor is at the left-most digit, the setting will be canceled.
SMART  MENU/SET 		Press the  button to apply the setting.	

Selection menu	Details
 (ON-delay timer)	<p>After the measurement result has been finalized, the timer delays turning ON of the PASS output for the time set to the timer.</p>  <p style="text-align: right;">← :Time set to timer</p>
 (OFF-delay timer)	<p>After the measurement result has been finalized, the timer delays turning OFF of the PASS output for the time set to the timer.</p>  <p style="text-align: right;">← :Time set to timer</p>

3 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
SMART  MENU/SET  Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS


External Input for Bank, Timing Input, Reset Input

[Setting channels used when connecting multiple units: Each CH, Bank switching: CH1]

External input:

This refers to inputting the bank switching signal, the timing signal during a hold and the reset signal from an external device to execute these operations.

Procedure for setting up external input











1 Set to the MENU mode





Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Hold down for 3 seconds</p>		Hold down the button for three seconds to switch to the MENU mode.	
<p>Press to display.</p>		Press the button to display <i>DETAIL L</i> .	* This step is not required if detail menu display is already set to ON in the MENU mode.
<p>Press to display.</p>		Press the button to set the display to <i>ON</i> to set display of the detail menu.	
		Press the button to apply the setting.	

2 External input terminal setting

Button Operation	Display	Description of Operation	Explanation of Selection Menu
<p>Press to display.</p>		Press the button to display <i>EXT-IN</i> .	<div style="border: 1px solid black; padding: 5px; display: inline-block;">Default value: TIM.RST</div>

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to select	 Select the desired value.	Press the  button to select the external input terminal.	 timing input/reset input  Bank switching
 		Press the  button to apply the setting.	

3 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 3 seconds		Hold down the  button for three seconds to switch to the RUN mode.	

Procedure for executing external input

Each of the functions is executed when signals are input using the external input wire in table 1 below.

Timing input, reset input and bank switching are executed by a signal input of 4 ms or more. While the signal in table 2 below is being input, measurement is performed based on the settings of the specified bank.

When connecting two or more Amplifier Units, use the CH1 Amplifier Unit for bank switching. The banks of the Amplifier Units of CH2 and later are switched together with CH1.

Table 1 External Input Wiring



Setting	Amplifier Unit Connector Cable Color	Purple	Red
			Timing input
		BANK input 0	BANK input 1

Table 2 Bank Signal Switching Wiring




	BANK Input 0 (purple)	BANK Input 1 (red)
BANK 0	OFF	OFF
BANK 1	ON	OFF
BANK 2	OFF	ON
BANK 3	ON	ON

(Note) Bank signal switching is enabled only in the RUN mode.




Key Lock Function:

The key lock function disables all keys. Once keys have been disabled, no key input will be accepted until the lock is released. This function is useful for preventing inadvertent changes to settings.

Key Lock Function

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 <p>Hold both down for 3 seconds</p>		Hold both the  buttons down for three seconds in the RUN mode.	

Canceling the Key Lock

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 <p>Hold both down for 3 seconds</p>		Hold both the  buttons down for three seconds in the RUN mode.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

Initializing Settings Data

Setting channels used when connecting multiple units: Each CH

Initialization: This function resets all settings to their default values.

Default Values

Function	Default Value
Display	0 reference: Measurement center distance + indication: NEAR side - indication: FAR side
HIGH threshold	Measurement range maximum value
LOW threshold	Measurement range minimum value
Response time	500 ms
Analog output setting	-5 to +5 V
Detail menu display selection	OFF
Bank switching settings	0
Mutual interference prevention	OFF
Hysteresis width	0.000
Two-Sensor operation setting	OFF
Thickness setting	0.000
Measured value display scaling	OFF
Hold setting	OFF
Trigger mode	TIMING (self-trigger timing input)
Self-trigger level	0.000
Output for non-measurement	KEEP
Clamp value	MAX
ON-delay time	0 ms
OFF-delay time	0 ms
Zero reset memory	OFF
Display during zero reset	0.000
External input terminal setting	TIM.RST (timing input/reset input)

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS


TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

Procedure for initializing settings data







Important













- When connecting two or more Amplifier Units, use CH1 to perform initialization because CH2 and later channels cannot be used to do this.

Note that CH2 and later channels are initialized together with CH1.







1 Set to the MENU mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  Hold down for 3 seconds		Hold down the  button for three seconds to switch to the MENU mode.	

2 Setting data initialization

Button Operation	Display	Description of Operation	Explanation of Selection Menu
 Press to display		Press the  button to display INI E.	
 Press to display.		Press the  button to display EXE.	
  Hold down	 Displayed 1 digit at a time	Press the  button.	
		When  is displayed, this means that initialization is completed.	

3 Return to RUN mode

Button Operation	Display	Description of Operation	Explanation of Selection Menu
  <p>Hold down for 3 seconds</p>	  	Hold down the  button for three seconds to switch to the RUN mode.	

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

**BASIC
SETUP**

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

**DETAILED
SETTINGS**

TRUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

TROUBLESHOOTING

Troubleshooting	120
Error Messages	122
Q&A	125

Troubleshooting

This section describes countermeasures for temporary hardware problems. Check the malfunction in this section before sending the hardware for repair.

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS

Category	Problem	Probable cause and possible countermeasure	Pages
Operation	The device restarts during operation.	<ul style="list-style-type: none"> • Is the power supply device connected correctly? • Are the Calculating Units connected correctly? 	p.28 p.25
	No input signal is received.	<ul style="list-style-type: none"> • Are all cables connected correctly? • Is the signal line disconnected? 	p.28
	The measured values fluctuate and are not stable depending on day and time.	<ul style="list-style-type: none"> • This problem may be due to temperature characteristics. Execute zero reset periodically using the standard object to correct this problem. 	p.97
	Laser light is not emitted.	<ul style="list-style-type: none"> • Is the LD-OFF input short-circuited? 	p.28
	Bank switching by signals from the external input terminal is not functioning.	<ul style="list-style-type: none"> • Is the external input terminal set to <i>BANK?</i> • Is the cable connected correctly? 	p.112 p.28
	The state returns to <i>BANK 0</i> in the RUN mode even if after a bank is switched by button operation.	<ul style="list-style-type: none"> • Is the external input terminal set to <i>ELMRSE?</i> 	p.112
	Display	The main display stays at [----].	<ul style="list-style-type: none"> • Has a timing input been made while hold is enabled and the the trigger mode is <i>ELMI NG?</i> • If the hold function is enabled and the trigger type is <i>SELF-U</i> or <i>SELF-d</i>, has the self-trigger level been set to an appropriate value?
An abnormal distance is displayed when the object is clearly outside the measurement range.		<ul style="list-style-type: none"> • This problem may occur due to the characteristics of the sensor. Make sure that the distance to the sensing object is appropriate. 	—
<i>LdDOWN</i> is displayed on the sub-display when the power is turned ON.		<ul style="list-style-type: none"> • The laser of the Sensor Head has deteriorated. Replace the Sensor Head. 	—
<i>LdOFF</i> is displayed on the sub-display.		<ul style="list-style-type: none"> • Is the LD-OFF input short-circuited? 	p.28
<i>ELMI NG</i> is displayed on the sub-display.		<ul style="list-style-type: none"> • Is the timing input short-circuited? 	p.28
<i>RESEt</i> is displayed on the sub-display.		<ul style="list-style-type: none"> • Is the reset input short-circuited? 	p.28
Even though the installation conditions are the same, measured values differ considerably.		<ul style="list-style-type: none"> • Is the zero-reset input short-circuited? 	p.28

Category	Problem	Probable cause and possible countermeasure	Pages
Display	<i>E-bRC</i> is displayed on the main display.	<ul style="list-style-type: none"> Is the distance between the Sensor Head and the workpiece within the measurement range? 	p.131
	<i>E-dARK</i> is displayed on the main display.	<ul style="list-style-type: none"> Is the distance between the Sensor Head and the workpiece within the measurement range? 	p.131
Output	Judgements are not output to external devices.	<ul style="list-style-type: none"> Are all cables connected correctly? Is the signal line disconnected? Are reset inputs short-circuited? Is the HIGH threshold set to a value larger than the LOW threshold? 	p.28
	Analog output levels are strange.	<ul style="list-style-type: none"> Are the analog output settings correct? 	p.105

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS











INDEX










SETTING TRANSITION CHARTS

Error Messages

This section outlines the error messages displayed on the Amplifier Unit and the countermeasures for those messages.

While displaying an error, the error output signal is also output. (There are some exceptions.)

Display	Error	Countermeasure
Error-bright 	Saturated light amount intensity, measurement error. (The error output signal is not output.)	<ul style="list-style-type: none"> Install so that the distance between the Sensor Head and the workpiece is within the measurement range.
Error-channel 	<ul style="list-style-type: none"> There is only one Amplifier Unit even though mutual interference prevention is set to ON. There is only one Amplifier Unit even though two-Sensor operation is set to ON. 	<ul style="list-style-type: none"> If two or more Amplifier Units have been installed, turn OFF the power supply and check that the Amplifier Units and Calculating Units are connected correctly. If only one Amplifier Unit is being used, connect another Amplifier Unit temporarily and turn OFF mutual interference prevention and two-Sensor operation, or initialize the setting data.
Error-channel 	Two Amplifier Unit communications error.	
Error-dark 	Insufficient received light intensity, measurement error. (The error output signal is not output.)	<ul style="list-style-type: none"> Install so that the distance between the Sensor Head and the workpiece is within the measurement range.
Error-head 	The Sensor Head is disconnected. Or, a sensor communications error has occurred.	<ul style="list-style-type: none"> Turn OFF the power supply, check the Sensor Head connection, and then turn ON the power supply again. If the above countermeasure does not solve the problem, the Sensor Head is malfunctioning. Replace the Sensor Head.
Error-head 		
Error-head 		
Error-head 		
Error-head 	The Sensor Head internal memory is in error.	
Error-head 		

Display	Error	Countermeasure
Error-head 	Sensor Head system error.	<ul style="list-style-type: none"> • Turn OFF the power supply, check the Sensor Head connection, and then turn ON the power supply again. • If the above countermeasure does not solve the problem, the Sensor Head is malfunctioning. Replace the Sensor Head.
Error-head 		
Error-head 		
Error-head 	Because the Sensor Head version is old, the connected Amplifier Unit cannot be used.	<ul style="list-style-type: none"> • Contact the company with which your company is doing business or the OMRON sales representative handling your company.
Error-memory 	Amplifier Unit setting memory error.	<ul style="list-style-type: none"> • Turn OFF the power supply, check if wiring is connected correctly, and then turn ON the power supply again. • If the above countermeasure does not solve the problem, the Amplifier Unit is malfunctioning. Replace the Amplifier Unit.
Error-memory 	Amplifier Unit setting memory error.	<ul style="list-style-type: none"> • Initialize the settings by holding down the SET key for at least three seconds. • If the above countermeasure does not solve the problem, the Amplifier Unit is malfunctioning. Replace the Amplifier Unit.
Error-short 	One or all of the judgment outputs are short-circuited.	<ul style="list-style-type: none"> • Turn OFF the power supply, check that the HIGH, PASS, LOW or error output lines are not short-circuited, then turn ON the power supply again.
Error-system 	Amplifier Unit system error.	<ul style="list-style-type: none"> • Turn OFF the power supply, check if wiring is connected correctly, and then turn ON the power supply again. • If the above countermeasure does not solve the problem, the Amplifier Unit is malfunctioning. Replace the Amplifier Unit.
Tuning-failed 	Smart Tuning failed. (The error output signal is not output.)	<ul style="list-style-type: none"> • Change the response time setting to a larger value, and try again. • Make sure that the distance between the Sensor and Workpiece is within the measurement range, and try again.

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENTFLOW OF
OPERATIONBASIC
SETUPMAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
WarpageDouble
Sheet
Detection



Thickness

Positioning

Eccentricity
and Surface
DeflectionDETAILED
SETTINGSTROUBLE-
SHOOTINGSPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

Display	Error	Countermeasure
LD.down 	The laser of the Sensor Head has deteriorated.	<ul style="list-style-type: none"> Replace the Sensor Head.
	Measured values are not output because the reset signal is being input, calculations are in progress, timing is before the hold sampling time, etc. (The error output signal is not output.)	<ul style="list-style-type: none"> Normally, measured values are displayed once they can be output.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TRUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

Question	Answer
What is the positional variation range with respect to the machine axis of the emitter beam spot?	The range is $\pm 0.5^\circ$ of the ideal emitter axis in the dimensional drawing on page 130.
After the response time is changed, is it necessary to re-execute smart tuning?	Yes. After the response time is changed, the smart tuning results are cleared. Therefore, re-execute tuning.
If using a different bank for the first time, is it necessary to execute smart tuning?	Yes. The smart tuning results are not applied to other banks. If using a different bank for the first time, execute smart tuning.
For the line beam type, is it possible to detect beam-spot-internal steps?	Spot-internal steps cannot be measured. Use the line beam spot so that it is at only one height.
Is it possible to add additional extension cables between the Sensor Head and Amplifier Unit?	Regardless of the length, only one extension cable can be added. It is not possible to add multiple extension cables.
About how much signal input and open time is required for each input operation?	These times can be checked using the timing charts in this manual (on page 133).
Can calculations be performed when Sensor Heads that have different measurement ranges are connected to two Amplifier Units?	Yes. This is possible without specifying any special settings.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

SPECIFICATIONS



Specifications and Dimensions	128
Timing Charts	133
Engineering Data (Typical)	136

Specifications and Dimensions


Amplifier Units

ZX2-LDA11/LDA41

(Unit: mm)



*1 Max. height when cover is open: 56
 *2 Min. length when connected: 50



CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

Item	Model	ZX2-LDA11	ZX2-LDA41
Measurement period (*1)		Min. 30 μ s	
Response time		60 μ s, 120 μ s, 240 μ s, 500 μ s, 1 ms, 2 ms, 4 ms, 8 ms, 12 ms, 20 ms, 36 ms, 66 ms, 128 ms, 250 ms, 500 ms	
Analog output (*2)		4 to 20 mA, Max. load resistance: 300 Ω , \pm 5 VDC or 1 to 5 VDC, Output impedance: 100 Ω	
Judgment outputs (HIGH/PASS/LOW: 3 outputs), error output		NPN open-collector outputs, 30 VDC, 50 mA max. residual voltage: 1 V max. for load current 10 mA max., 2 V max. for load current above 10 mA	PNP open-collector outputs, 30 VDC, 50 mA max. residual voltage: 1 V max. for load current 10 mA max., 2 V max. for load current above 10 mA
Laser OFF input, zero reset input, timing input, reset input, bank input		ON: Short-circuited with 0-V terminal or 1.2 V or less. OFF: Open (leakage current: 0.1 mA max.)	ON: Supply voltage short-circuited or supply voltage within -1.2 V OFF: Open (leakage current: 0.1 mA max.)
Functions		Smart tuning, scaling, sample hold, peak hold, bottom hold, peak-to-peak hold, self-peak hold, self-bottom hold, average hold, zero reset, On-delay timer, OFF-delay timer, keep/clamp switch, (A-B) calculations (*3), thickness calculation (*3), mutual interference prevention (*3), laser deterioration detection, bank function (4 banks)	
Indications		Judgement indicators: HIGH (orange), PASS (green), LOW (orange), 11-segment main display (red), 11-segment sub-display (orange), laser ON (green), zero reset (green), ENABLE (green), MENU (green), HIGH threshold (orange), LOW threshold (orange)	
Power supply voltage		10 to 30 VDC, including 10% ripple(p-p)	
Power consumption		3,000 mW max. with power supply voltage of 30 VDC and power supply current of 100 mA max. (with Sensor connected)	
Ambient temperature		Operating: 0 to +50°C, Storage: -15 to +70°C (with no icing or condensation)	
Ambient humidity		Operating and storage: 35% to 85% (with no condensation)	
Dielectric strength		1,000 VAC, 50/60 Hz for 1 min.	
Vibration resistance (destruction)		10 to 150 Hz, 0.7–mm double amplitude, 80 min. each in X, Y, and Z directions	
Shock resistance (destruction)		300 m/s ² 3 times each in six directions (up/down, left/right, forward/backward)	
Degree of protection		IEC60529, IP40	
Connection method		Prewired (standard cable length: 2 m)	
Weight (packed state)		Approx. 200 g (main unit only: approx. 135 g)	
Materials		Case: PBT (polybutylene terephthalate), Cover: Polycarbonate, Display: Acrylic resin, Buttons: Polyacetal, Cable: PVC	
Accessories		Instruction sheet	

(*1) In the case of a white ceramic OMRON standard object

(*2) In the MENU mode, select and set current output (4 to 20 mA) and voltage output (\pm 5 V or 1 to 5 V).

(*3) A Calculating Unit (ZX2-CAL) is required.

Mutual interference prevention is possible for up to five Amplifier Units, and calculations are possible for up to two.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS


INDEX

SETTING TRANSITION CHARTS

Sensor Heads

ZX2-LD50/LD50L
ZX2-LD100/LD100L


(Unit: mm)



Sensor Head Extension Cables

ZX2-XC1R
ZX2-XC4R
ZX2-XC9R

(Unit: mm)



*L Cable lengths are as follows:
ZX2-XC1R: 1 m, ZX2-XC4R: 4 m, ZX2-XC9R: 9 m
Note. Two or more extension cables cannot be connected in series.

Item	Model	ZX2-LD50L	ZX2-LD50	ZX2-LD100L	ZX2-LD100
Optical system	Diffuse reflective				
Light source (wave length)	Visible-light semiconductor laser with a wavelength of 660 nm and an output of 1mW max.				
	EN class 2, FDA class II (*5)				
Measurement center distance	50 mm			100 mm	
	±10 mm			±35 mm	
Beam shape	Line	Spot		Line	Spot
Beam size (*1)	Approx. 60 μm x 2.6 mm	Approx. 60 μm dia.		Approx. 110 μm x 2.7 mm	Approx. 110 μm dia.
Resolution (*2)	1.5 μm			5 μm	
Linearity (*3)	±0.05% F.S. (40 to 50 mm)	±0.1% F.S. (40 to 50 mm)		±0.05% F.S. (65 to 100 mm)	±0.1% F.S. (65 to 100 mm)
	±0.1% F.S. (entire range)	±0.15% F.S. (entire range)		±0.1% F.S. (entire range)	±0.15% F.S. (entire range)
Temperature characteristic (*4)	0.02% F.S./°C				
Ambient illumination	Incandescent lamp: 10,000 lx max. (on light receiving side)				
Ambient temperature	Operating: 0 to +50°C, Storage: -15 to +70°C (with no icing or condensation)				
Ambient humidity	Operating and storage: 35% to 85% (with no condensation)				
Dialectic strength	1,000 VAC, 50/60 Hz for 1 min.				
Vibration resistance (destruction)	10 to 150 Hz, 0.7–mm double amplitude, 80 min. each in X, Y, and Z directions				
Shock resistance (destruction)	300 m/s ² 3 times each in six directions (up/down, left/right, forward/backward)				
Degree of protection	IEC60529, IP67				
Connection method	Connector connection (standard cable length: 500 mm)				
Weight (packed state)	Approx. 160 g (main unit only: approx. 75 g)				
Materials	Case and cover: PBT (polybutylene terephthalate), Optical window: Glass, Cable: PVC				
Accessories	Instruction sheet, Ferrite core, Laser warning label (English), FDA certification label				

(Note) Highly reflective objects can result in incorrect detection by causing out-of-range measurements.

(*1) Beam size: The beam size is defined by $1/e^2$ (13.5%) of the strength of the beam at the beam center (measured value).

Incorrect detection may occur if there is light leakage outside the defined spot and the material around the sensing object is more reflective than the sensing object.

(*2) Resolution: The resolution is the deviation ($\pm 3\sigma$) in the analog output when connected to the ZX2-LDA Amplifier Unit. (The resolution is measured with the standard reference object (white ceramic), at the measurement point when the response time of the ZX2-LDA is set to 128 ms.)

The resolution is given at the repeat accuracy for a stationary workpiece, and is not an indication of the distance accuracy.

The resolution may be adversely affected under strong electromagnetic fields.

(*3) Linearity: The linearity is given as the error in an ideal straight line displacement output when measuring the standard reference object.

The linearity and measurement values vary with the object being measured. F.S. is the entire measurement range. (ZX2-LD50□:20mm)

(*4) Temperature characteristic: The temperature characteristic is measured at the measurement center distance with the Sensor and reference object (OMRON's standard reference object) secured with an aluminum jig.

(*5) Categorized as Class 2 by EN60825-1 criteria in accordance with the stipulations of the FDA standard Laser Notice No.50, and registered with CDRH (Center for Devices and Radiological Health) (accession number: 1020665-000)

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS



INDEX

SETTING TRANSITION CHARTS

Calculating Unit

ZX2-CAL

(Unit: mm)



Item	Model	ZX2-CAL
Applicable Amplifier Units		ZX2-LDA11/ZX2-LDA41
Current consumption		12 mA max. (supplied from the Smart Sensor Amplifier Unit)
Ambient temperature		Operating: 0 to +50°C, Storage: -15 to +70°C (with no icing or condensation)
Ambient humidity		Operating and storage: 35% to 85% (with no condensation)
Connection method		Connector
Dielectric strength		1,000 VAC, 50/60 Hz for 1 min.
Vibration resistance (destruction)		10 to 150 Hz, 0.7 mm double amplitude, 80 min. each in X, Y, and Z directions
Shock resistance (destruction)		300 m/s ² 3 times each in six directions (up/down, left/right, forward/backward)
Materials		Case: ABS, Display: Acrylic resin
Weight (packed state)		Approx. 50 g (main unit only: approx. 15 g.)
Accessories		Instruction sheet

Timing Charts

This section explains the timing charts for the I/O signals that are exchanged between the Controller and external devices.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS


TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS


Laser OFF input



①	Laser emission ON → OFF	If laser OFF input is ON for 4 ms or more, the signal is received, and laser emission is turned OFF within 8 ms.
②	Laser emission OFF → ON	If laser OFF input is OFF for 4 ms or more, the signal is received, and laser emission is turned ON within 20 ms.

(*) The value is within 150 ms when mutual interference prevention is set to ON.

Reset input



①	Output value reset execution	If reset input is ON for 4 ms or more, the signal is received, and output is reset within 4 ms.
②	Output value reset cancellation	If reset input is OFF for 4 ms or more, measurement is resumed. Acquire the measurement results after the preset response time elapses. (*2)


(*1) The value is within 150 ms when mutual interference prevention is set to ON.

(*2) When connecting two or more Amplifier Units, acquire the measurement results after the response time specified for connecting two or more units elapses. (See page 82.)

Bank input

- When only one Amplifier Unit is used

Example) Switching from bank 2 to bank 1




(*) Bank input is executed by the ON/OFF combinations of BANK input 0 and BANK input 1.

If a bank input signal is input for 4 ms or more, the bank is determined, the bank is switched within 20 ms, and then measurement is resumed.

Acquire the measurement results after the preset response time elapses.

- When connecting two or more Amplifier Units

Example) Switching from bank 2 to bank 1




(*) Bank input is executed by the ON/OFF combinations of CH1 BANK input 0 and CH1 BANK input 1 when connecting two or more Amplifier Units.

If a CH1 bank input signal is input for 4 ms or more, the bank is determined, the bank is switched within 50 ms if mutual interference prevention is set to OFF, and within 420 ms if mutual interference prevention is set to ON, and then measurement is resumed.

Acquire the measurement results after the response time specified for connecting two or more Amplifier Units elapses. **(See page 82.)**


Zero reset input

- When the zero reset memory setting is OFF



①	Zero reset execution	Turn OFF after 4 ms to 1 s zero reset input turns ON. The zero reset is executed, and measurement is resumed within 5 ms. Acquire the measurement results after the preset response time elapses. (*)
②	Zero reset cancellation	Turn OFF after zero reset input turns ON for 3 s or more. The zero reset is canceled, and measurement is resumed within 5 ms. Acquire the measurement results after the preset response time elapses. (*)

- When the zero reset memory setting is ON



①	Zero reset execution	Turn OFF after 4 ms to 1 s zero reset input turns ON. The zero reset is executed, and measurement is resumed within 400 ms. Acquire the measurement results after the preset response time elapses. (*)
②	Zero reset cancellation	Turn OFF after zero reset input turns ON for 3 s or more. The zero reset is canceled, and measurement is resumed within 400 ms. Acquire the measurement results after the preset response time elapses. (*)

(*) When connecting two or more Amplifier Units, acquire the measurement results after the response time specified for connecting two or more units elapses. (See page 82.)

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS



Engineering Data (Typical)

Angle Characteristic



The angle characteristic is a plot of the inclination of the sensing object in the measurement range and the maximum value of the error to analog output.

Note: SUS304 = Stainless steel SUS304



ZX2-LD50





ZX2-LD50L




ZX2-LD100



ZX2-LD100L



Linearity Characteristic for Different Materials



* X axis distance: Measurement distance displayed on the Amplifier Unit
 For the measurement distance displayed on the Amplifier Unit, the measurement center distance is displayed as 0, and the NEAR and FAR sides from the sensor are displayed by + and -, respectively.

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING


SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

Beam Size

■ Spot Beams




ZX2-LD50

L	+10 mm	0 mm	-4 mm	-10 mm
X	Approx. 600 μ m	Approx. 160 μ m	Approx. 40 μ m	Approx. 220 μ m
Y	Approx. 350 μ m	Approx. 90 μ m	Approx. 60 μ m	Approx. 130 μ m

ZX2-LD100

L	+35 mm	0 mm	-20 mm	-35 mm
X	Approx. 1.1 mm	Approx. 400 μ m	Approx. 70 μ m	Approx. 250 μ m
Y	Approx. 550 μ m	Approx. 190 μ m	Approx. 110 μ m	Approx. 150 μ m

■ Line Beams



ZX2-LD50L

L	+10 mm	0 mm	-4 mm	-10 mm
X	Approx. 2.6 mm	Approx. 2.6 mm	Approx. 2.6 mm	Approx. 2.6 mm
Y	Approx. 350 μ m	Approx. 90 μ m	Approx. 60 μ m	Approx. 130 μ m

ZX2-LD100L

L	+35 mm	0 mm	-20 mm	-35 mm
X	Approx. 2.1 mm	Approx. 2.5 mm	Approx. 2.7 mm	Approx. 2.9 mm
Y	Approx. 550 μ m	Approx. 190 μ m	Approx. 110 μ m	Approx. 150 μ m

Note. L: Measurement distance displayed on the Amplifier Unit (For the measurement distance displayed on the Amplifier Unit, the measurement center distance is displayed as 0, and the NEAR and FAR sides from the sensor are displayed by + and -, respectively.)

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

INDEX

Numerics

1.5V (analog output 1 to 5 V)	105
2-sensor operation (thickness)	58
2-sensor operation (A-B)	48
4.20mA (analog output 4 to 20 mA)	105
-5.5V (analog output ±5 V)	105

A

A-B (2-sensor operation A-B)	48
Active Smart Tuning	81
Amplifier Unit	
Connecting the Sensor Head to the Amplifier Unit	27
Connecting Two or More Amplifier Units	82
Installing	24
Part Names and Functions	19
Specifications and Dimensions	128
Analog Output	105
Angle Characteristic	136
A-OUT (analog output)	105
AVE (hold measured value average)	42, 52, 60, 74, 90

B

BANK (bank switching)	96, 113
Bank Setting	95
Bank Switching	96, 113
Basic Configuration	18
BASIC SETUP	38
Beam Size	131, 138
AVE (hold minimum value)	42, 52, 60, 74, 90

C

CLC (2-sensor operation)	48, 58
Calculating Unit	
Connecting	25
Part Names and Functions	22
Specifications and	

Dimensions	132
Canceling the Key Lock	114
CLAMP (output for non-measurement clamp/clamp value)	108
Clamp value	108
Connecting	
Calculating Unit	25
Sensor Head and Amplifier Unit	27
Connecting the Sensor Head to the Amplifier Unit	27

D

Default Settings	115
Default Value	115
DETAIL (detail menu display)	40, 46, 50, 56, 64, 70, 84, 87, 89, 95, 98, 101, 107, 110, 112
Display of RUN Mode	38
Double Sheet Detection	50

E

E-BRGT	121, 122
E-CH	122
E-DARK	122
E-HEAD	122, 123
E-MEM	123
Engineering Data (Typical)	
Angle Characteristic	136
Beam Size	138
Linearity Characteristic for Different Materials	137
Error Messages	122
E-SHRT	123
E-SYS	123
External Input	112
EXT-IN (external input)	112

F

FLOW OF OPERATION	34
-------------------	----

H

Hold	42, 52, 60, 73, 89
------	--------------------

CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

CONTENTS
INTRODUCTION
PREPARATION FOR MEASUREMENT
FLOW OF OPERATION
BASIC SETUP
MAIN APPLICATIONS & SETTING METHODS
Height
Steps and Warpage
Double Sheet Detection
Thickness
Positioning
Eccentricity and Surface Deflection
DETAILED SETTINGS
TROUBLE-SHOOTING
SPECIFICATIONS
INDEX
SETTING TRANSITION CHARTS

<i>HOLD</i> (hold)	42, 52, 60, 73, 90
<i>HYS</i> (hysteresis width)	88
Hysteresis	87

I	
I/O Circuit Diagrams	
PNP Amplifier Unit	32
<i>INIT</i> (initialization)	116
Initialization	115
Installing	
Amplifier Unit	24
Sensor Head	23

K	
<i>KEEP</i> (output for non-measurement keep)	108
Key Lock Function	114
<i>K-LOCK</i> (key lock enabled)	114

L	
<i>LddOWN</i>	124
LD-OFF input	29
Linearity Characteristic for Different Materials	137

M	
Main Display	19, 20
<i>MAX</i> (clamp value MAX)	108
Measuring Eccentricity and Surface Deflection	70
Measuring Height	40
Measuring Thickness	55
Multi Smart Tuning	80
Mutual Interference Prevention	46, 56, 84

N	
I/O Circuit Diagrams	
NPN Amplifier Unit	31

O	
OFF-delay timer	110
<i>OFFtM</i> (OFF-delay timer)	110
ON-delay timer	110
<i>ONtM</i> (ON-delay timer)	110
Output for Non-measurement	107

P	
Part Names and Functions	18
Amplifier Unit	19

Calculating Unit	22
Sensor Head	22

<i>PEAK</i> (hold peak)	42, 52, 60, 74, 90
Positioning	64

PREPARATION FOR MEASUREMENT	17
-----------------------------	----

<i>PtP</i> (hold peak-to-peak)	42, 52, 60, 74, 90
--------------------------------	--------------------

Q	
Q&A	125

R	
Reset Input	113
Reset input	30
Response time	46, 51, 56, 65, 71, 78

<i>RStOUT</i>	
(output for non-measurement)	108

S	
<i>S1-AFt</i> (scaling S1-Aft)	67, 72, 102, 103
<i>S1-bEF</i> (scaling S1-Bef)	67, 72, 102, 103
<i>S2-AFt</i> (scaling S2-Aft)	68, 73, 103
<i>S2-bEF</i> (scaling S2-Bef)	68, 73, 103
<i>SAMPLE</i> (hold sample)	42, 52, 60, 74, 90
<i>SCALE</i> (scaling)	66, 72, 101
Scaling	66, 72, 101
<i>SELF-d</i> (self-trigger self-d)	43, 53, 61, 75, 92
<i>SELFlv</i> (self-trigger level)	43, 53, 61, 75, 93
<i>SELF-U</i> (self-trigger self-u)	43, 53, 61, 75, 92
Sensor Head	
Part Names and Functions	22
Specifications and Dimensions	130
Sensor Head extension cable	130
Sensor Heads: Installing	23
Setting Transition Charts	144

Simplest Setting	38
Single Smart Tuning	
38, 41, 47, 51, 57, 66, 71, 79	
Smart Tuning	
38, 41, 47, 51, 57, 66, 71, 78	
<i>SMART/ACTIVE</i>	81
<i>SMART/MULTI</i>	80
<i>SMART/SINGLE</i>	
38, 41, 47, 51, 57, 66, 71, 79	
Specifications and Dimensions	
Amplifier Unit	128
Calculating Unit	132
Sensor Head	130
<i>SPEED</i> (response time)	
41, 46, 51, 56, 65, 71, 78	
Steps and Warpage	45
Sub-display	19, 20
<i>SYNC</i>	
(mutual interference prevention)	
46, 56, 85	

T

<i>THICK</i>	
(2-sensor operation thickness)	
58	
Threshold Setting	
44, 48, 54, 62, 69, 76	
Timer	110
<i>TIMING</i> (self-trigger timing input)	
43, 53, 61, 75, 92	
Timing Charts	133
Timing input	93, 113
<i>TRMSE</i> (timing input/reset input)	
113	
<i>TRIG</i> (self-trigger)	
42, 52, 61, 74, 92	
Troubleshooting	120
<i>TUNING/MULTI</i>	80
<i>TUNING/SINGLE</i>	
38, 41, 47, 51, 57, 66, 71, 79	

W

Wiring Diagram	28
Wiring Input/Output Cables	28

Z

Zero Reset	97
Zero reset cancellation	100
<i>ZRdI SP</i>	
(display setting at zero reset)	
99	
<i>ZRMEM</i> (zero reset memory)	98

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

CONTENTS

INTRODUCTION

PREPARATION
FOR
MEASUREMENT

FLOW OF
OPERATION

BASIC
SETUP

MAIN
APPLICATIONS
& SETTING
METHODS

Height

Steps
and
Warpage

Double
Sheet
Detection

Thickness

Positioning

Eccentricity
and Surface
Deflection

DETAILED
SETTINGS

TROUBLE-
SHOOTING

SPECIFI-
CATIONS

INDEX

SETTING
TRANSITION
CHARTS

Revision History

A manual revision code appears as a suffix to the catalog number at the bottom of the front and back covers of this manual.


Cat. No. Z310-E1-02

↑
Revision code

Revision code	Date	Revised contents
01	Oct. 2010	Original production
02	Jan. 2011	General revision


SETTING TRANSITION CHARTS

- CONTENTS
- INTRODUCTION
- PREPARATION FOR MEASUREMENT
- FLOW OF OPERATION
- BASIC SETUP
- MAIN APPLICATIONS & SETTING METHODS
- Height
- Steps and Warpage
- Double Sheet Detection
- Thickness
- Positioning
- Eccentricity and Surface Deflection
- DETAILED SETTINGS
- TROUBLE-SHOOTING
- SPECIFICATIONS
- INDEX
- SETTING TRANSITION CHARTS



Bank switching
 ★ : Default Value*
 : Main Display
 : Sub-display
 * The default threshold and scaling values in the figure assume those for ZX2-LD50(L).

[Single unit]: Only one amplifier unit is used
 [CH1]: Amplifier unit CH1 among connected units
 [CH2]: Amplifier unit CH2 or later among connected units
 [CH1*]: Amplifier unit CH1 among connected units with mutual interference prevention on
 [CH2*]: Amplifier unit CH2 or later among connected units with mutual interference prevention on



CONTENTS

INTRODUCTION

PREPARATION FOR MEASUREMENT

FLOW OF OPERATION

BASIC SETUP

MAIN APPLICATIONS & SETTING METHODS

Height

Steps and Warpage

Double Sheet Detection

Thickness

Positioning

Eccentricity and Surface Deflection

DETAILED SETTINGS

TROUBLE-SHOOTING

SPECIFICATIONS

INDEX

SETTING TRANSITION CHARTS

OMRON Corporation Industrial Automation Company

Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Sensor Business Unit

Carl-Benz-Str. 4, D-71154 Nufringen, Germany

Tel: (49) 7032-811-0/Fax: (49) 7032-811-199

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2),

Alexandra Technopark,

Singapore 119967

Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONICS LLC

One Commerce Drive Schaumburg,

IL 60173-5302 U.S.A.

Tel: (1) 847-843-7900/Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower,

200 Yin Cheng Zhong Road,

PuDong New Area, Shanghai, 200120, China

Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200

Authorized Distributor:

© OMRON Corporation 2010 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. Z310-E1-02

Printed in Japan
(1101)