Error code PSENcode/PSENslock



PSEN sensor technology

1 Note

This document contains the error code description of the PSENcode and PSENslock ranges. The operating manuals of these devices are currently being revised. In future, they will include the descriptions of the error codes.

2 Error code

The "Safety Gate" and "Input" LEDs send flash signals; an error code can be established from the number and sequence. The "Power/Fault" LED illuminates red.

Each error code is indicated by three short flashes of the "Input" or "Safety Gate" LED. After a longer pause, the LED will then flash at one second intervals. The number of LED flashes corresponds to a digit in the error code. The error code can consist of up to 3 digits. The digits are separated by a longer period without flashing. The entire sequence is constantly repeated.


Number of flashes	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
Decimal error code	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 0

LED	Error	Remedy
LEDs unlit.	Supply voltage is missing, too low, wrongly connected	Connect supply voltage: A1 - +24 VDC and A2 – 0 VDC
"Input" LED flashes yellow.	Partial operation in the input circuit	Open both channels of the input circuit.
"Power/Fault" LED illuminates red.	Error message	Read error codes for fault diagnostics
"Safety Gate" or "Input" LEDs flash a code and "Power/Fault" LED illuminates red.	For error codes see table below	See table below

Example:

Error code 1,4,1:

Flash frequency of the "Safety Gate" or "Input" LED



Meaning of flash frequency:

	Flash frequency	Meaning
I	3 times, short	Code for error message
II	Once, for one second each	Code for 1st digit
Ш	4 times, for one second each	Code for 2nd digit
IV	Once, for one second each	Code for 3rd digit
V	3 times, short	Code for error message repeated

Table of error codes

Error code Decimal	Number of flashes	Description	Remedy
1.4.1	3x short – 1x long – 4x long – 1x long – 3x short	At least one of the two safety outputs 12 and 22 have voltage applied during system run-up	Check the wiring of safety outputs 12 and 22, rectify the wiring error
1.12	3x short – 1x long – 12x long – 3x short	During operation, short circuit between safety output 12 and 0 VDC	Rectify wiring error at safety output 12
1.13	3x short – 1x long – 12x long – 3x short	During operation, short circuit between safety output 22 and 0 VDC	Rectify wiring error at safety output 22
14	3x short – 14x long – 3x short	During operation, short circuit between safety output 12 and 24 VDC	Rectify wiring error at safety output 12
15	3x short – 15x long – 3x short	During operation, short circuit between safety output 22 and 24 VDC	Rectify wiring error at safety output 22
4.10.7	3x short– 4x long, 10x long, 7x long– 3x short	2 actuators are within the sensor's response range.	Remove one of the actuators from the response range; comply with the actuator's max. approach speed.

Other flashing codes signal an internal error. Remedy: Change device.



Technical support is available from Pilz round the clock.

Americas	Australia
Brazil	+61 3 95446300
+55 11 97569-2804	
Canada	Europe
+1 888-315-PILZ (315-7459)	Austria
Mexico	+43 1 7986263-0
+52 55 5572 1300	Belgium, Luxembourg
USA (toll-free)	+32 9 3217575
+1 877-PILZUSA (745-9872)	France
	+33 3 88104000
Asia	Germany
China	+49 711 3409-444
+86 21 60880878-216	Ireland
Japan	+353 21 4804983
+81 45 471-2281	Italy
South Korea	+39 0362 1826711
+82 31 450 0680	

Scandinavia +45 74436332 Spain +34 938497433 Switzerland +41 62 88979-30 The Netherlands +31 347 320477 Turkey +90 216 5775552 United Kingdom

+44 1536 462203

You can reach our international hotline on: +49 711 3409-444 support@pilz.com

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies.

Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.









Pilz GmbH & Co. KG Felix-Wankel-Straße 2 73760 Ostfildern, Germany

Tel.: +49 711 3409-0 Fax: +49 711 3409-133

info@pilz.com www.pilz.com



CMSE *, InduraNET p *, PAS4000 *, PAScal *, PASconfig *, Pilz *, PIIT *, PLID *, PMCprimo *, PMCprotego *, PMCtendo *, PMD *, PMI *, PNOZ *, Primo *, PSEN *, PVIS *, Safety Safety Safety MIS p *, the spirit of safety * are registered and protected todemarks of Pils GmbH & Co. KG in some countries. We would point out that product features may vary from the details stated in this document, depending on the status at the time of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy from entire training on the status at the time of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy and entirely of the text and graphics presented in this information. Please contact our Technical Support if you have any questions.